| Original | | Replacement | |
|---|---|---|---|
| digital | Digital | MEDIA DISPLAY | Display / Media |
| theater modes | Yellow/Theater Modes | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Power | | Power |
| cd | CD | SHIFT + CD-STB 3 | Shift + 3 |
| dvd | DVD | SHIFT + DVD 2 | Shift + 2 |
| stereo | Green/Stereo | APP REPEAT | Green / APP / Repeat |
| delay | Blue/Delay | Prime Video RANDOM | Blue / Prime Video / Random |
| dts | Red/Center | NETFLIX SEARCH | Red / Netflix / Search |
| up | Up | | Up |
| level | Violet/Level | PC FAV MARKER | Fav / Marker / PC |
| tape | Tape | SHIFT + TAPE 5 | Shift + 5 |
| sat/cab | SAT/CAB | SHIFT + HDMI - SAT 0 | Shift + 0 |
| tuner | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| video /vcr | Video/VCR | SHIFT + VIDEO 4 | Shift + 4 |
| – | Left/- | | Left |
| ok | OK | OK | OK |
| + | Right/+ | | Right |

| Original | | Replacement | |
|---|---|---|---|
| pty rep. | PTY | GOTO TEXT | Text / Goto |
| down | Down | | Down |
| RDS mix | Menu/RDS | HOME MENU | Menu / Home |
| | Vol + | + VOL | Vol + |
| pr+ | PR+ | + CH PAGE | CH+ / Page+ |
| | Vol - | VOL – | Vol - |
| pr– | PR- | CH PAGE – | CH- / Page- |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |

| Original | | Replacement | |
|---|---|---|---|
| memo | Memo | LIST SMART | Smart / List |
| 0 | 0 | HDMI - SAT 0 | 0 |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | | Replacement | |
|---|---|---|---|
| digital | Digital | MEDIA DISPLAY | Display / Media |
| theater modes | Yellow/Theater Modes | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Power | | Power |
| cd | CD | SHIFT + CD-STB 3 | Shift + 3 |
| dvd | DVD | SHIFT + DVD 2 | Shift + 2 |
| stereo | Green/Stereo | APP REPEAT | Green / APP / Repeat |
| delay | Blue/Delay | Prime Video RANDOM | Blue / Prime Video / Random |
| dts | Red/Center | NETFLIX SEARCH | Red / Netflix / Search |
| up | Up | | Up |
| level | Violet/Level | PC FAV MARKER | Fav / Marker / PC |
| tape | Tape | SHIFT + TAPE 5 | Shift + 5 |
| sat/cab | SAT/CAB | SHIFT + HDMI-SAT 0 | Shift + 0 |
| tuner | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| video /vcr | Video/VCR | SHIFT + VIDEO 4 | Shift + 4 |
| – | Left/- | | Left |
| ok | OK | OK | OK |
| + | Right/+ | | Right |

| Original | | Replacement | |
|---|---|---|---|
| down | Down | | Down |
| RDS | Menu/RDS | HOME MENU | Menu / Home |
| | Vol + | VOL + | Vol + |
| pr+ | PR+/ >>I | PRESET+ | >>I / Preset+ |
| pr+ | PR+/ >>I | CH PAGE + | CH+ / Page+ |
| | Vol - | VOL – | Vol - |
| pr– | PR-/ I << | PRESET- | I << / Preset- |
| pr– | PR-/ I << | CH PAGE – | CH- / Page- |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |

| Original | | Replacement | |
|---|---|---|---|
| 9 | 9 | 9 | 9 |
| memo | Memo | SMART | Smart / List |
| 0 | 0 | 0 | 0 |
| REV | << | TUNE- | << / Tune- |
| PLAY | Play | SLOW | Play / Slow |
| FWD | >> | TUNE+ | >> / Tune+ |
| DISC REC vcr | Rec | REC MODE | Rec / Rec Mode |
| STOP | Stop | HOLD | Stop / Hold |
| PAUSE | Pause | STEP-FREEZE | Pause / Step / Freeze |

| Original | Replacement |
|---|---|
| | |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| digital | Digital | MEDIA DISPLAY | Display / Media | pty rep. | PTY | GOTO TEXT | Text / Goto |
| theater modes | Yellow/Theater Mo | YouTube REPEAT A-B | Yellow / YouTube / Repeat | down | Down | ▼ | Down |
| power | Power | power | Power | RDS mix | Menu/RDS | HOME MENU | Menu / Home |
| cd | CD | SHIFT + CD-STB 3 | Shift + 3 | vol + | Vol + | + VOL | Vol + |
| dvd | DVD | SHIFT + DVD 2 | Shift + 2 | pr+ | PR+/ >>I | + CH PAGE | CH+ / Page+ |
| stereo | Green/Stereo | APP REPEAT | Green / APP / Repeat | vol - | Vol - | VOL – | Vol - |
| delay | Blue/Delay | Prime Video RANDOM | Blue / Prime Video / Random | pr– | PR-/I << | CH PAGE – | CH- / Page- |
| dts | Red/Center | NETFLIX SEARCH | Red / Netflix / Search | mute | Mute | DIMMER MUTE | Mute / Dimmer |
| up | Up | ▲ | Up | 1 | 1 | TV 1 | 1 |
| level | Violet/Level | PC FAV MARKER | Fav / Marker / PC | 2 | 2 | DVD 2 | 2 |
| tape | Tape | SHIFT + TAPE 5 | Shift + 5 | 3 | 3 | CD-STB 3 | 3 |
| sat/cab | SAT/CAB | SHIFT + HDMI-SAT 0 | Shift + 0 | 4 | 4 | VIDEO 4 | 4 |
| tuner | Tuner | SHIFT + TUNER 6 | Shift + 6 | 5 | 5 | TAPE 5 | 5 |
| video /vcr | Video/VCR | SHIFT + VIDEO 4 | Shift + 4 | 6 | 6 | TUNER 6 | 6 |
| - | Left/- | ◀ | Left | 7 | 7 | AUX-HDD 7 | 7 |
| ok | OK | OK | OK | 8 | 8 | USB 8 | 8 |
| + | Right/+ | ▶ | Right | 9 | 9 | BLUETOOTH 9 | 9 |

| Original | | Replacement | |
|---|---|---|---|
| memo | Memo | LIST SMART | Smart / List |
| 0 | 0 | HDMI - SAT 0 | 0 |
| REV | << | TUNE- | << / Tune- |
| PLAY | Play | SLOW | Play / Slow |
| FWD | >> | TUNE+ | >> / Tune+ |
| DISC REC vcr | Rec | REC MODE | Rec / Rec Mode |
| STOP | Stop | HOLD | Stop / Hold |
| PAUSE | Pause | STEP - FREEZE | Pause / Step / Freeze |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| digital | Digital | MEDIA DISPLAY | Display / Media | + | Right / + | ▶ | Right |
| theater modes | Yellow/Theater Modes | YouTube REPEAT A-B | Yellow / YouTube / Repeat | pty rep. | PTY | GOTO TEXT | Text / Goto |
| ⏻ | Power | ⏻ | Power | down | Down | ▼ | Down |
| cd | CD | SHIFT + CD-STB 3 | Shift + 3 | RDS mix | Menu/RDS | HOME MENU | Menu / Home |
| dvd | DVD | SHIFT + DVD 2 | Shift + 2 | RDS mix | Menu/RDS | RDS AV INPUT | AV / Input / RDS |
| stereo | Green/Stereo | APP REPEAT | Green / APP / Repeat | + | Vol + | + VOL | Vol + |
| delay | Blue/Delay | Prime Video RANDOM | Blue / Prime Video / Random | + pr+ | PR+/ >>I | + CH PAGE | CH+ / Page+ |
| dts | Red/Center | LANG I/II AUDIO | Audio / Lang I/II | + pr+ | PR+/ >>I | PRESET+ ⏭ | >>I / Preset+ |
| dts | Red/Center | NETFLIX SEARCH | Red / Netflix / Search | – | Vol - | VOL – | Vol - |
| up | Up | ▲ | Up | – pr– | PR-/ I << | CH PAGE – | CH- / Page- |
| level | Violet/Level | PC FAV MARKER | Fav / Marker / PC | – pr– | PR-/ I << | PRESET- ⏮ | I << / Preset- |
| tape | Tape | SHIFT + TAPE 5 | Shift + 5 | | Mute | DIMMER MUTE | Mute / Dimmer |
| sat/cab | SAT/CAB | SHIFT + HDMI-SAT 0 | Shift + 0 | 1 | 1 | TV 1 | 1 |
| tuner | Tuner | SHIFT + TUNER 6 | Shift + 6 | 2 | 2 | DVD 2 | 2 |
| video /vcr | Video/VCR | SHIFT + VIDEO 4 | Shift + 4 | 3 | 3 | CD-STB 3 | 3 |
| – | Left/- | ◀ | Left | 4 | 4 | VIDEO 4 | 4 |
| OK | OK | OK | OK | 5 | 5 | TAPE 5 | 5 |

| Original | | Replacement | |
|---|---|---|---|
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| memo | Memo | LIST SMART | Smart / List |
| 0 | 0 | HDMI - SAT 0 | 0 |
| REV | << | TUNE- | << / Tune- |
| PLAY | Play | SLOW | Play / Slow |
| FWD | >> | TUNE+ | >> / Tune+ |
| DISC REC vcr | Rec | REC MODE | Rec / Rec Mode |
| STOP | Stop | HOLD | Stop / Hold |
| PAUSE | Pause | STEP - FREEZE | Pause / Step / Freeze |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |