Original		Replacement	
POWER	Power		Power
STANDBY	Standby	SHIFT +	Shift + Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
CD	CD	SHIFT + CD-STB 3	Shift + 3
MD CD-R	MD/CD-R	SHIFT + TAPE 5	Shift + 5
DVD	DVD	SHIFT + DVD 2	Shift + 2
CBL DTV	D-TV/CBL	SHIFT + TV 1	Shift + 1
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
MULTI CH IN	Multi CH In	SHIFT + HDMI-SAT 0	Shift + 0
V-AUX	V-AUX	SHIFT + AUX-HDD 7	Shift + 7
DVR	DVR	SHIFT + VIDEO 4	Shift + 4
VOLUME +	Volume +	VOL +	Vol +
VOLUME –	Volume -	VOL –	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STEREO 1	Stereo	TV 1	1
MUSIC 2	Music	DVD 2	2
ENTERTAIN 3	Entertain	CD-STB 3	3

Original		Replacement	
MOVIE 4	Movie	VIDEO 4	4
STANDARD 5	Standard	TAPE 5	5
SELECT 6	Select	TUNER 6	6
EXTD SUR. 7	Extd Sur.	AUX-HDD 7	7
DIRECT ST 8	Direct ST	USB 8	8
SPEAKERS 9	Speakers	BLUETOOTH 9	9
ENHANCER 0	Enhancer	-/-- GUIDE EPG	Guide / EPG / -/--
NIGHT +10	Night	HDMI-SAT 0	0
STRAIGHT ENT. EFFECT	Straight	PC FAV MARKER	Fav / Marker / PC
LEVEL TITLE BAND	Level	TITLE SOUND	Sound / Title
PRESET/CH ^	Up / Preset/CH +	▲	Up
SET MENU MENU SRCH MODE	Set Menu	HOME MENU	Menu / Home
– <	Left/-	◀	Left
ENTER	Enter	OK	OK
A/B/C/D/E > +	Right/+	▶	Right
RETURN DAB MEMORY	Return	RETURN BACK	Back / Return
v	Down / Preset/CH -	▼	Down

Original	Replacement	Original	Replacement
DISPLAY Display	MEDIA DISPLAY Display / Media		

Original		Replacement	
POWER	Power		Power
STANDBY	Standby	SHIFT +	Shift + Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
CD	CD	SHIFT + CD-STB 3	Shift + 3
MD CD-R	MD/CD-R	SHIFT + TAPE 5	Shift + 5
DVD	DVD	SHIFT + DVD 2	Shift + 2
CBL DTV	DTV/CBL	SHIFT + TV 1	Shift + 1
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
MULTI CH IN	Multi CH In	SHIFT + HDMI - BAT 0	Shift + 0
V-AUX	V-AUX / Dock	SHIFT + AUX - HDD 7	Shift + 7
DVR	DVR	SHIFT + VIDEO 4	Shift + 4
+ VOLUME	Volume +	+ VOL	Vol +
VOLUME –	Volume -	VOL –	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STEREO 1	1	TV 1	1
MUSIC 2	2	DVD 2	2
ENTERTAIN 3	3	CD-STB 3	3

Original		Replacement	
MOVIE 4	4	VIDEO 4	4
STANDARD 5	5	TAPE 5	5
SELECT 6	6	TUNER 6	6
EXTD SUR 7	7	AUX - HDD 7	7
DIRECT ST 8	8	USB 8	8
SPEAKERS 9	9	BLUETOOTH 9	9
ENHANCER 0	0	HDMI - BAT 0	0
STRAIGHT ENT. EFFECT	ENT	PC FAV MARKER	Fav / Marker / PC
LEVEL TITLE BAND	Band	TITLE SOUND	Sound / Title
PRESET/CH	Preset +		Up
PRESET/CH	Preset +	PRESET+	>>I / Preset +
SET MENU MENU SRCH MODE	Srch Mode	HOME MENU	Menu / Home
	Left / A/B/C/D/E		Left
ENTER	Enter	OK	OK
	Right /		Right
RETURN DAB MEMORY	Return	RETURN BACK	Back / Return
	Preset -		Down

Original	Replacement	Original	Replacement
Preset-	I<< / Preset-		
Display	Display / Media		
Freq/Text	Red / Netflix / Search		
PTY Seek Mode	Yellow / YouTube / Repeat		
PTY Seek Start	Blue / Prime Video / Random		
EON	Green / APP / Repeat		