Original	Replacement
Open / Close	Eject / Surround
Power	Power
Mute	Mute / Dimmer
System	Menu / Home
Go To	Text / Goto
L/R	D.Menu / Top
Program	TV/Radio /
Repeat	Green / APP / Repeat
Rep A-B	Yellow / YouTube / Repeat
Random	Blue / Prime Video / Random
Audio	Audio / Lang I/II
1	1
2	2
3	3
Subtitle	Subtitle / EQ
4	4
5	5

Original	Replacement
6	6
Angle	Info / Angle
7	7
8	8
9	9
Digest	Sleep / Timer
0	0
10+	Guide / EPG / -/--
Clear	Exit / Cancel / Clear
I<< SKip	I<< / Preset-
Skip >>I	>>I / Preset+
<< Scan	<< / Tune-
Scan >>	>> / Tune+
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Title	Sound / Title

Original	Replacement	Original	Replacement
PBC	Picture / Format		
Up	Up		
Left	Left		
Select	OK		
Right	Right		
OSD	Display / Media		
Down	Down		
Return	Back / Return		
Zoom	Zoom / Size		
Slow	Shift + Play /		
Step	Shift + Pause / Step /		
Resume	Rec / Rec Mode		
Setup	Setup / OPT /		
Function	Smart / List		
-	Vol-		
+	Vol+		