Original		Replacement	
	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CD►/II	Play/Pause CD	SLOW ►	Play / Slow
USB ►/II	Play/Pause USB	STEP-FREEZE II	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
⏮/◀◀	I<<<< / <<	TUNE- ◀◀	<< / Tune-
▶▶/⏭	>>/ >>I	TUNE+ ▶▶	>> / Tune+
MUSIC PORT	Music Port	LANG I/II AUDIO	Audio / Lang I/II
BASS	Bass	TITLE SOUND	Sound / Title
SURROUND	Surround	SURROUND ⏏	Eject / Surround
AUTO PRESET	Auto Preset	FORMAT PICTURE	Picture / Format
TUNE MODE	Tune Mode	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
D.BASS	D. Bass	OPT-TOOLS SETUP	Setup / OPT /
PRESET EQ	Preset EQ	EQ SUBTITLE	Subtitle / EQ
TREBLE	Treble	TOP MENU D.MENU	D. Menu / Top
▲	Up	▲	Up

Original		Replacement	
FM/AM	FM/AM	PROGRAM TV/RADIO	TV/Radio /
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
AUTO OFF	Auto Off	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▼	Down	▼	Down
+ VOL	Vol +	+ VOL	Vol +
DEL	Del	RETURN BACK	Back / Return
VOL −	Vol -	VOL −	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7

Original		Replacement		Original	Replacement
8	8	8	8		
9	9	9	9		
≧10	>10	GUIDE EPG	Guide / EPG / -/--		
0	0	0	0		
FM MODE	FM Mode	FAV MARKER	Fav / Marker / PC		
PLAY MODE	Play Mode	NETFLIX SEARCH	Red / Netflix / Search		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
PLAY	Timer Play	Prime Video RANDOM	Blue / Prime Video / Random		
PROGRAM	Program	HOME MENU	Menu / Home		
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer		
CLOCK/TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer		
RE-MASTER	Re-Master	LIST SMART	Smart / List		
INPUT LEVEL	Input Level	RDS AV INPUT	AV / Input / RDS		