Original		Replacement	
STANDBY	Standby		Power
DTV/VCR	DTV/VCR	HOME SMART	Smart
TEXT	Text	REPEAT TEXT	Text
VOL+	Vol +	+ VOL	Vol +
VOL-	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
INFO	Info	DISPLAY INFO	Info
EPG	EPG	-/-- GUIDE	Guide
PLAY/PAUSE	Play	PLAY MODE	Play
PLAY/PAUSE	Pause		Pause
STOP	Stop		Stop
REV	<<		<<
FWD	>>		>>
PREV	I <<		I <<
NEXT	>>I		>>I
SETUP	Setup	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit

Original		Replacement	
SOURCE	Source	TIMER AV	AV
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R
CH+	CH+	+ CH	Ch +
CH-	CH-	CH −	Ch -
CH+	Up		Up
CH-	Down		Down
FAV+	Right / FAV+		Right
FAV-	Left / FAV-		Left
ENTER	Enter	OK	Ok
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8

Original		Replacement		Original	Replacement
9	9	9	9		
0	0	0	0		
RECALL	Recall	RETURN BACK	Back		
GOTO	Goto	ECO 3D	3D		
FAVORITE	Favorite	FAV PRE-CH	Pre Ch		
MODE	Mode	APP MEDIA	Media		
AUDIO	Audio	SHIFT +	SOUND DUAL	Shift + Dual	
LANGUAGE	Language	SOUND DUAL	Dual		
REPEAT	Red/ Repeat	A	Red		
A-B	Green/ A-B	B	Green		
ZOOM	Yellow/ Zoom	C	Yellow		
SUBTITLE	Blue/ Subtitle	D	Blue		