Mandis shop

Wave Music System IV

Original		Replacement	
STOP ALARM	Power / Stop		Power
SLEEP BUZZER	Sleep / Buzzer	TIMER SLEEP	Sleep / Timer
	Mute	DIMMER MUTE	Mute / Dimmer
RADIO	Radio	SHIFT + TUNER 6	Shift + 6
RADIO	Radio	NETFLIX SEARCH	Red / Netflix / Search
CD	CD	APP REPEAT	Green / APP / Repeat
CD	CD	SHIFT + CD-STB 3	Shift + 3
AUX	AUX	YouTube REPEAT A-B	Yellow / YouTube / Repeat
AUX	AUX	SHIFT + AUX-HDD 7	Shift + 7
	Vol +	VOL +	Vol +
1	Presets 1	TV 1	1
2	Presets 2	DVD 2	2
3	Presets 3	CD-STB 3	3
	Vol -	VOL −	Vol -
4	Presets 4	VIDEO 4	4
5	Presets 5	TAPE 5	5
6	Presets 6	TUNER 6	6

Original		Replacement	
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Open / Close	SURROUND	Eject / Surround
TUNE /	< Tune/MP3	TUNE-	<< / Tune-
E / MP3	Tune/MP3 >	TUNE+	>> / Tune+
TIM	Time-	CH PAGE −	CH- / Page-
IME	Time+	+ CH PAGE	CH+ / Page+
PLAY MODE	Play Mode	LIST SMART	Smart / List
ALARM 1	Alarm On/Off	OK	OK
ALARM 2	Alarm Wake To		Right
ALARM SETUP MENU	Alarm		Left
ALARM SETUP MENU	Alarm	HOME MENU	Menu / Home

https://mandisshop.eu/BOSE-Wave-Music-System-IV-replacement-remote-control-for-BOSE-Wave-Music-System-IV.htm