Original	Replacement	Original	Replacement
Power	Power	TV	TV/R
Source	AV	Recall	Pre Ch
Vol +	Vol +	World	Media
Vol -	Vol -	Menu	Menu
Mute	Mute	Exit	Exit
PR+	Ch +	Back	Back
PR-	Ch -	i/Info	Info
1	1	Guide	Guide
2	2	[≡]/Text	Text
3	3	*/O	Format
4	4	*/O..	3D
5	5	Lang	Dual
6	6	[≡]..	Subt
7	7	[-O-]	Options
8	8	Red	Red
9	9	Green	Green
0	0	Yellow	Yellow

Original		Replacement		Original	Replacement
	Blue	D	Blue		
	Rec	REC MODE	Rec		
	Play	PLAY MODE	Play		
	Stop		Stop		
	Pause		Pause		
	<<		<<		
	>>		>>		
OK	OK	OK	Ok		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	Music/Photo/Movi	HOME SMART	Smart		
Q. MENU	Q. Menu	E-MANUAL D.MENU	D. Menu		