Original	Replacement	Original	Replacement
POWER Power	Power	TXT/MIX TXT/MIX	Text
SLEEP Sleep	Sleep	TXT/MIX Play	Play
MUTE Mute	Mute	TXT/MIX Pause	Pause
MODE Mode	SC NA Media	CANCEL Stop	Stop
1 1	1	REC Rec	Rec
2 2	IST 2	INDEX >>/Index	>>
3 3	3	HOLD <<</Hold	<<
4 4	4	SIZE I<<	I<<
5 5	PROG 5	REVEAL >>I	>>I
6 6	6	CANCEL Cancel	Exit
7 7	7	MENU Menu	P Menu
8 8	LEEP 8	DTV/RADIO DTV/Radio	TV/R
9 9	9	VOL+ Vol +	Vol +
0 0	0	VOL- Vol -	Vol -
+ -/--	+ Shift + Guide	Up	AY MOD Up
BACK Back	Back	Down	Down
NICAM/A2 Nicam/A2	Dual	Right	Right

Original	Replacement	Original	Replacement
Left	Left	FAV-	+ Shift + Ch -
Enter	Ok		
CH+	Ch +		
CH-	Ch -		
FAV	Pre Ch		
EPG	Guide		
Info	Info		
List	List		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		
Size	Format		
Reveal	3D		
Subtitle	Subt		
Subpage	AV		
FAV+	+ Shift + Ch +		

Original	Replacement	Original	Replacement
Power	Power	Vol +	Vol +
Mute	Mute	Vol -	Vol -
[I] / Menu	Menu	CH+	Ch +
Exit	Exit	CH-	Ch -
Source	AV	Up	Up
1	1	Down	Down
2	2	Right	Right
3	3	Left	Left
4	4	OK	Ok
5	5	Recall	Back
6	6	Info	Info
7	7	EPG	Guide
8	8	Freeze	Options
9	9	Red	Red
0	0	Green	Green
Subtitle	Subt	Yellow	Yellow
Text	Text	Blue	Blue

Original	Replacement	Original	Replacement
Audio	Dual		
I <<</ [≡+]	I <<		
>>I / [≡ .]	>>I		
[≡i]	Smart		
Play	Play		
Pause	Pause		
Stop	Stop		
REP/ Rec	Rec		
<<</ [≡o]	<<		
>>/ [≡?]	>>		
FAV	Pre Ch		