Original	Replacement	Original	Replacement
OFF	SHIFT + Power	Tuning+	>> / Tune+
ON / Source	Power	DVD/VDP	2
Power DVD/VDP	Red / Netflix / Search	TV/DBS	1
Power VCR	Green / APP / Repeat	VCR-1	4
Power	Yellow / YouTube / Repeat	Tuning-	<< / Tune-
Power TV	Blue / Prime Video / Random	VCR-2	8
Dolby/DTS	Eject / Surround	V. AUX	7
Dolby/DTS	Picture / Format	CDR/TAPE	5
Dolby/DTS	Sound / Title	Channel +	CH+ / Page+
DSP Simulation	Subtitle / EQ	Channel -	CH- / Page-
Direct	Zoom / Size	Mode	Play / Slow
Stereo	Audio / Lang I/II	Memory	Pause / Step / Freeze
Virtual Surround	Sleep / Timer	Band	Stop / Hold
5CH/6CH / Stereo	TV/Radio /	Shift	Rec / Rec Mode
PHONO	9	Play CD/MD/CDR-DVD/	SHIFT + SLOW Shift + Play /
CD	3	Stop CD/MD/CDR-DVD/	SHIFT + HOLD Shift + Stop /
TUNER	6	Vol +	Vol +

Original	Replacement
I << CD/MD/CDR-DVD/	Shift + I << / Preset-
>>I CD/MD/CDR-DVD/	Shift + >>I / Preset+
Vol -	Vol -
<< CD/MD/CDR-DVD/	Shift + << /
>> CD/MD/CDR-DVD/	Shift + >> /
Pause CD/MD/CDR-DVD/	Shift + Pause / Step /
Disc Skip+	D.Menu / Top
Muting	Mute / Dimmer
Setup	Setup / OPT /
Up	Up
Surround	Info / Angle
Left	Left
CH.Select / Ente	OK
Right	Right
Status / Displa	Display / Media
Down	Down
Surround / Back Return	Back / Return

Original	Replacement
Test Tone	Text / Goto
Video Select	Smart / List
Dimmer	Shift + Mute / Dimmer
Speaker	AV / Input / RDS
Input Mode	Guide / EPG / -/--
Input Analog	0
Input Ext-In	Fav / Marker / PC