Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	AUX	5	5
MEDIA PLAYER	Media Player	6	6
PHONO	Phono	7	7
TV AUDIO	TV Audio	8	8
TUNER	Tuner	9	9
USB	USB	-/-- GUIDE	Guide
Bluetooth	Bluetooth	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
	·:I:·	APP MEDIA	Media
ECO	Eco	ECO 3D	3D
CH/PAGE	CH/Page Up	+ CH	Ch +

Original		Replacement	
CH/PAGE	CH/Page Down	CH –	Ch -
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TUNE –	I<</Tune-		I<<
	Play	PLAY MODE	Play
	Pause		Pause
TUNE +	>>I/Tune+		>>I

Original		Replacement	
1	Quick Select 1	E-MANUAL D.MENU	D. Menu
2	Quick Select 2	REPEAT TEXT	Text
3	Quick Select 3	ZOOM	Eject
4	Quick Select 4	TIMER AV	AV
MOVIE	Green/Movie	B	Green
MUSIC	Red/Music	A	Red
GAME	Blue/Game	D	Blue
PURE	Yellow/Pure	C	Yellow

Original	Replacement

https://mandisshop.tv/en/Denon/10326-524-replacement-remote-control-for-Denon-RC1227-3701250001-1-1-1

Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	AUX	5	5
MEDIA PLAYER	Media Player	6	6
PHONO	Phono	7	7
TV AUDIO	TV Audio	8	8
TUNER	Tuner	9	9
USB	USB	-/-- GUIDE	Guide
Bluetooth	Bluetooth	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
	·:I:·	APP MEDIA	Media
CH/PAGE	CH/Page Up	+ CH	Ch +
CH/PAGE	CH/Page Down	CH –	Ch -

Original		Replacement	
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
BACK	Back	RETURN BACK	Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TUNE –	I<<Tune-		I<<
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause
TUNE +	>>I/Tune+		>>I
1	Quick Select 1	E-MANUAL D.MENU	D. Menu
2	Quick Select 2	REPEAT TEXT	Text
3	Quick Select 3	ZOOM	Eject
4	Quick Select 4	TIMER AV	AV