Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	FAV		Pre Ch
	TXT		Text
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

Original		Replacement	
	Guide		Guide
	?		Dual
	Exit		Exit
	Menu		Menu
	Back		Back
	Tools		Options
	@		TV/R
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol +		Vol +
	Vol -		Vol -
	PR+		Ch +
	PR-		Ch -
	Source		AV

Original		Replacement		Original	Replacement
	Mute	MUTE	Mute		
	I<		I<<		
	>I		>>I		
	<<		<<		
	>>		>>		
	Rec	REC MODE	Rec		
	Play	PLAY MODE	Play		
	Pause		Pause		
	Stop		Stop		
3D	3D	ECO 3D	3D		
	Q	PICTURE FORMAT	Format		
	[...]..	AD SUBT	Subt		
NETFLIX	Netflix	SHIFT + APP MEDIA	Shift + Media		
MY MEDIA	My Media	APP MEDIA	Media		