Original		Replacement	
ON POW	Power On		Power
OFF WER	Power Off	SHIFT +	Shift + Power
1 SPEAK	Speakers 1	+ CH PAGE	CH+ / Page+
2 KERS	Speakers 2	CH PAGE −	CH- / Page-
Phono	PHONO	SHIFT + USB 8	Shift + 8
CD	CD	SHIFT + CD-STB 3	Shift + 3
VID 1	VID 1	SHIFT + TV 1	Shift + 1
VID 2	VID 2	SHIFT + DVD 2	Shift + 2
VID 3	VID 3	SHIFT + VIDEO 4	Shift + 4
FM	FM	SHIFT + TUNER 6	Shift + 6
AM	AM	SHIFT + AUX-HDD 7	Shift + 7
Tape Mon	TAPE MON	SHIFT + TAPE 5	Shift + 5
FM Mode	FM Mode	MEDIA DISPLAY	Display / Media
Auto Preset	Auto Preset	LIST SMART	Smart / List
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3

Original		Replacement	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
DIRECT	Direct	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MEMORY	Memory	PC FAV MARKER	Fav / Marker / PC
▲	Up	▲	Up
MENU	Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
PRESET SCAN	Preset Scan	ANGLE INFO	Info / Angle
▼	Down	▼	Down

Original	Replacement
Vol +	Vol +
Mute	Mute / Dimmer
Tune Up	>> / Tune+
Vol -	Vol -
Tune Down	<< / Tune-
Preset Down	I<< / Preset-
Preset Up	>>I / Preset+
Dimmer	Shift + Mute / Dimmer
Sleep	Sleep / Timer

Original	Replacement