Original		Replacement		Original		Replacement	
	Power		Power	Q.VIEW	Q. Vi ew	MEDIA DISPLAY	Di spl ay / Medi a
TV/RAD	Tv/ Radi o	PROGRAM TV/RADIO	TV/ Radi o /		Vol +	VOL	Vol +
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ	FAV	FAV	PC FAV MARKER	Fav / Marker / PC
AD	AD	LANG I/II AUDIO	Audi o / Lang I/II	P PAGE	PR+	CH PAGE	CH+ / Page+
RATIO	[ ]/ Ratio	FORMAT PICTURE	Picture / Format		Vol -	VOL	Vol -
INPUT	I nput	RDS AV INPUT	AV / I nput / RDS	GUIDE	Gui de	-/-- GUIDE EPG	Gui de / EPG / -/--
1	1	TV 1	1	P PAGE	PR-	CH PAGE	CH- / Page-
2	2	DVD 2	2	MUTE	Mute	DIMMER MUTE	Mute / Di mmer
3	3	CD - STB 3	3	TEXT	Text	GOTO TEXT	Text / Goto
4	4	VIDEO 4	4	INFO	I nfo	ANGLE INFO	I nfo / Angl e
5	5	TAPE 5	5	T.OPT	T. OPT	TOP MENU D.MENU	D. Menu / Top
6	6	TUNER 6	6	SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
7	7	AUX - HDD 7	7		Up		Up
8	8	USB 8	8	Q.MENU	Q Menu	HOME MENU	Menu / Home
9	9	BLUETOOTH 9	9		Left		Left
LIST	List	LIST SMART	Smart / List	OK	OK	OK	OK
0	0	HDMI - SAT 0	0		Ri ght		Ri ght

Original		Replacement		Original		Replacement	
BACK	Back	RETURN BACK	Back / Return				
	Down		Down				
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
AV MODE	AV Mode	SURROUND	Eject / Surround				
REC/*	Rec/*	REC MODE	Rec / Rec Mode				
■	Stop	HOLD ■	Stop / Hold				
◀◀	<<	TUNE- ◀◀	<< / Tune-				
▶	Play	SLOW ▶	Play / Slow				
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				
●	Red	NETFLIX SEARCH	Red / Netflix / Search				
●●	Green	APP REPEAT	Green / APP / Repeat				
●●●	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
●●●●	Blue	Prime Video RANDOM	Blue / Prime Video / Random				