Original		Replacement	
	Power		Power
INPUT	Input	RDS AV INPUT	AV / Input / RDS
ON	Monitor On	LIST SMART	Smart / List
MONITOR OFF	Monitor Off	MEDIA DISPLAY	Display / Media
ENERGY SAVING	Energy Saving	TIMER SLEEP	Sleep / Timer
3D	3D	SIZE ZOOM	Zoom / Size
1	1	TV 1	1
2 ABC	2	DVD 2	2
3 DEF	3	CD-STB 3	3
4 GHI	4	VIDEO 4	4
5 JKL	5	TAPE 5	5
6 MNO	6	TUNER 6	6
7 PQRS	7	AUX-HDD 7	7
8 TUV	8	USB 8	8
9 WXYZ	9	BLUETOOTH 9	9
1/a/A	1/a/A	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0

Original		Replacement	
CLEAR	Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
	Vol +	VOL +	Vol +
ARC	ARC	OPT-TOOLS SETUP	Setup / OPT /
BRIGHTNESS (PAGE)	Brightness (Page Up	CH PAGE +	CH+ / Page+
BRIGHTNESS (PAGE)	Brightness (Page Down	CH PAGE −	CH- / Page-
	Vol -	VOL −	Vol -
AUTO	Auto	PROGRAM TV/RADIO	TV/Radio /
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PSM	PSM	GOTO TEXT	Text / Goto
INFO	Info	ANGLE INFO	Info / Angle
W.BAL	W Bal	EQ SUBTITLE	Subtitle / EQ
SETTINGS	Settings	HOME MENU	Menu / Home
	Up		Up
S.MENU	S. Menu	TOP MENU D.MENU	D. Menu / Top
	Left		Left
OK	OK	OK	OK
	Right		Right

Original		Replacement		Original		Replacement	
BACK	Back	RETURN BACK	Back / Return				
▼	Down	▼	Down				
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
SIMPLINK	Simplink	FORMAT PICTURE	Picture / Format				
TILE	Tile	TITLE SOUND	Sound / Title				
■	Stop	HOLD ■	Stop / Hold				
◀◀	<<	TUNE- ◀◀	<< / Tune-				
▶	Play	SLOW ▶	Play / Slow				
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				
ON PICTURE	Red/Picture ID C	NETFLIX SEARCH	Red / Netflix / Search				
OFF PICTURE ID	Green/Picture ID Off	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				