Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
SET	O/F. Set	TIMER SLEEP	Sleep / Timer
LIST	[ ]/F. List	LIST SMART	Smart / List
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	[+]/Picture	FORMAT PICTURE	Picture / Format
REC-MENU	-[ ]←/Rec Menu	TOP MENU D.MENU	D.Menu / Top
RADIO	Radio/Search	PROGRAM TV/RADIO	TV/Radio /
RADIO	Radio/Search	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD-STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX-HDD 7	7
8 tuv	8	USB 8	8

Original		Replacement	
9 wxyz	9	BLUETOOTH 9	9
DVD-AV EPG	*EPG	-/-- GUIDE EPG	Guide / EPG / -/--
0 AV	0/AV	HDMI-SAT 0	0
0 AV	0/AV	RDS AV INPUT	AV / Input / RDS
# PIP	#PIP	OPT-TOOLS SETUP	Setup / OPT /
DISC.M TEXT	Text	GOTO TEXT	Text / Goto
MENU	Menu	HOME MENU	Menu / Home
END	End	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INFO	Info	ANGLE INFO	Info / Angle
P+	P+	CH+ PAGE	CH+ / Page+
	Up		Up
V-	Vol -	VOL -	Vol -
	Left		Left
OK	OK	OK	OK
	Down		Down
V+	Vol +	VOL +	Vol +
	Right		Right

Original		Replacement		Original	Replacement
	P-		CH- / Page-		
	Red/C-Set		Red / Netflix / Search		
	Green/SV		Green / APP / Repeat		
	Yellow/Title		Sound / Title		
	Yellow/Title		Yellow / YouTube / Repeat		
	Blue/Card		Blue / Prime Video / Random		
	<<		<< / Tune-		
	Play		Play / Slow		
	>>		>> / Tune+		
	Rec		Rec / Rec Mode		
	Pause		Pause / Step / Freeze		
	Stop		Stop / Hold		

Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
DVD-AV EPG	*EPG	-/-- GUIDE EPG	Guide / EPG / -/--
0 AV	0/AV	RDS AV INPUT	AV / Input / RDS
0 AV	0/AV	HDMI - SAT 0	0
# PIP	#PIP	FORMAT PICTURE	Picture / Format
MENU	Menu	HOME MENU	Menu / Home
INFO	Info	ANGLE INFO	Info / Angle

Original		Replacement	
P+	P+	CH PAGE +	CH+ / Page+
	Up		Up
V-	Vol -	VOL -	Vol -
	Left		Left
OK	OK	OK	OK
	Down		Down
V+	Vol +	VOL +	Vol +
	Right		Right
P-	P-	CH PAGE -	CH- / Page-
C-SET	Red/C-Set	NETFLIX SEARCH	Red / Netflix / Search
SV	Green/SV	APP REPEAT	Green / APP / Repeat
TITLE	Yellow/Title	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TITLE	Yellow/Title	TITLE SOUND	Sound / Title
CARD	Blue/Card	Prime Video RANDOM	Blue / Prime Video / Random
	<<	TUNE- <<	<< / Tune-
	Play	SLOW ▶	Play / Slow
	>>	TUNE+ >>	>> / Tune+

Original	Replacement	Original	Replacement
Rec	Rec / Rec Mode		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		

Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
SET	O/F. Set	TIMER SLEEP	Sleep / Timer
LIST	[ ]/F. List	LIST SMART	Smart / List
	Audio/Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
	Audio/Repeat	LANG I/II AUDIO	Audio / Lang I/II
	[+]/Picture	FORMAT PICTURE	Picture / Format
REC-MENU	→[ ]←/Rec Menu	GOTO TEXT	Text / Goto
RADIO	Radio/Search	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
RADIO	Radio/Search	PROGRAM TV/RADIO	TV/Radio /
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD-STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX-HDD 7	7

Original		Replacement	
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
DVD-AV EPG	DVD-AV	RDS AV INPUT	AV / Input / RDS
0 AV	0/AV	HDMI-SAT 0	0
# PIP	#PIP	OPT-TOOLS SETUP	Setup / OPT /
DISC-M TEXT	Disc-M	TOP MENU D.MENU	D.Menu / Top
MENU	Menu	HOME MENU	Menu / Home
END	End	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INFO	Info	ANGLE INFO	Info / Angle
P+	P+	CH PAGE +	CH+ / Page+
	Up		Up
V-	Vol -	VOL -	Vol -
	Left		Left
OK	OK	OK	OK
	Down		Down
V+	Vol +	VOL +	Vol +
	Right		Right

Original		Replacement		Original	Replacement
	P-		CH- / Page-		
	Red/C-Set		Red / Netflix / Search		
	Green/SV		Green / APP / Repeat		
	Yellow/Title		Yellow / YouTube / Repeat		
	Yellow/Title		Sound / Title		
	Blue/Card		Blue / Prime Video / Random		
	<<		<< / Tune-		
	Play		Play / Slow		
	>>		>> / Tune+		
	Rec		Rec / Rec Mode		
	Pause		Pause / Step / Freeze		
	Stop		Stop / Hold		

Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
SET	O/F. Set	TIMER SLEEP	Sleep / Timer
LIST	[ ]/F. List	LIST SMART	Smart / List
	Audio/Repeat	APP REPEAT	Green / APP / Repeat
	Audio/Repeat	LANG I/II AUDIO	Audio / Lang I/II
	[+]/Picture	FORMAT PICTURE	Picture / Format
REC-MENU	→[ ]←/Rec Menu	TOP MENU D.MENU	D.Menu / Top
RADIO	Radio/Search	NETFLIX SEARCH	Red / Netflix / Search
RADIO	Radio/Search	PROGRAM TV/RADIO	TV/Radio /
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7

Original		Replacement	
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
DVD-AV EPG	*EPG	-/-- GUIDE EPG	Guide / EPG / -/--
0 AV	0/AV	HDMI - SAT 0	0
0 AV	0/AV	RDS AV INPUT	AV / Input / RDS
# PIP	#PIP	OPT-TOOLS SETUP	Setup / OPT /
MENU	Menu	HOME MENU	Menu / Home
END	End	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INFO	Info	ANGLE INFO	Info / Angle
P+	P+	CH PAGE +	CH+ / Page+
	Up		Up
V-	Vol -	VOL −	Vol -
	Left		Left
OK	OK	OK	OK
	Down		Down
V+	Vol +	VOL +	Vol +
	Right		Right

Original		Replacement		Original	Replacement
	P-		CH- / Page-		
	<<		<< / Tune-		
	Play		Play / Slow		
	>>		>> / Tune+		
	Rec		Rec / Rec Mode		
	Pause		Pause / Step / Freeze		
	Stop		Stop / Hold		