Original	Replacement
Power	Power
CBL/SAT	SHIFT + HDMI - SAT 0 — Shift + 0
DVD	SHIFT + DVD 2 — Shift + 2
TV/Audio	PROGRAM TV/RADIO — TV/Radio /
Blu-ray	SHIFT + TV 1 — Shift + 1
AUX1	SHIFT + AUX - HDD 7 — Shift + 7
Tuner	SHIFT + TUNER 6 — Shift + 6
Bluetooth	SHIFT + BLUETOOTH 9 — Shift + 9
Game	SHIFT + TAPE 5 — Shift + 5
AUX2	RDS AV INPUT — AV / Input / RDS
Phono	LANG I/II AUDIO — Audio / Lang I/II
iPod/USB	-/-- GUIDE EPG — Guide / EPG / -/--
Media Player	MEDIA DISPLAY — Display / Media
CD	SHIFT + CD - STB 3 — Shift + 3
Online Music	TITLE SOUND — Sound / Title
Internet/Radio	SHIFT + PROGRAM TV/RADIO — Shift + TV/Radio / Program
CH+	CH+ / Page+

Original	Replacement
Vol +	VOL + — Vol +
CH-	CH PAGE − — CH- / Page-
Sleep	TIMER SLEEP — Sleep / Timer
Mute	DIMMER MUTE — Mute / Dimmer
Vol -	VOL − — Vol -
Info	ANGLE INFO — Info / Angle
Up	Up
Option	SHIFT + OPT-TOOLS SETUP — Shift + Setup / OPT / Tools
Left	Left
Enter	OK — OK
Right	Right
Back	RETURN BACK — Back / Return
Down	Down
Setup	OPT-TOOLS SETUP — Setup / OPT /
Home	HOME MENU — Menu / Home
Stop	HOLD ■ — Stop / Hold
Pause	STEP - FREEZE ❚❚ — Pause / Step / Freeze

Original		Replacement	
	Play	SLOW	Play / Slow
	I<<<Tune-	PRESET-	I<< / Preset-
	>>I / Tune+	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Smart Select 1	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
	Smart Select 2	SHIFT + APP REPEAT	Shift + Green / APP /
	Smart Select 3	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
	Smart Select 4	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
	Green	APP REPEAT	Green / APP / Repeat
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	4	VIDEO 4	4

Original		Replacement	
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	0	HDMI-SAT 0	0

Original	Replacement
Power	Power
CBL/SAT	Setup / OPT /
DVD	Shift + 2
TV/Audio	TV/Radio /
Blu-ray	AV / Input / RDS
AUX1	Picture / Format
Tuner	Shift + 6
Bluetooth	Shift + 9
Game	Shift + Setup / OPT / Tools
AUX2	Subtitle / EQ
Phono	Audio / Lang I/II
iPod/USB	Guide / EPG / -/--
Media Player	Display / Media
CD	Shift + 3
Online Music	Shift + Fav / Marker / PC
Internet/Radio	Shift + TV/Radio / Program
CH+	CH+ / Page+

Original	Replacement
Vol +	Vol +
CH-	CH- / Page-
Sleep	Sleep / Timer
Mute	Mute / Dimmer
Vol -	Vol -
Up	Up
Left	Left
Enter	Fav / Marker / PC
Right	Right
Back	Back / Return
Down	Down
Home	Menu / Home
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Play	Play / Slow
I<<Tune-	I<< / Preset-
>>I/Tune-	>>I / Preset+

Original		Replacement		Original	Replacement
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
ENTER	Enter	OK	OK		