| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | OK | OK | Ok |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| V+ | Vol + | + VOL | Vol + |
| V- | Vol - | VOL − | Vol - |
| P+ | PR+ | + CH | Ch + |
| P- | PR- | CH − | Ch - |
| EXIT | Exit | CLEAR EXIT | Exit |
| BACK | Back | RETURN BACK | Back |
| | Red | A | Red |
| | Green | B | Green |
| | Yellow | C | Yellow |
| | Blue | D | Blue |
| INFO | Info | DISPLAY INFO | Info |

| Original | | Replacement | |
|---|---|---|---|
| MENU | Menu | TOP MENU MENU | Menu |
| | Mute | MUTE | Mute |
| SOURCE | Source | TIMER AV | AV |
| SWAP | Swap | FAV PRE-CH | Pre Ch |
| 0 | 0 | 0 | 0 |
| 1 | 1 | 1 | 1 |
| 2 ABC | 2 | 2 | 2 |
| 3 DEF | 3 | 3 | 3 |
| 4 GHI | 4 | 4 | 4 |
| 5 JKL | 5 | 5 | 5 |
| 6 MNO | 6 | 6 | 6 |
| 7 PQRS | 7 | 7 | 7 |
| 8 TUV | 8 | 8 | 8 |
| 9 WXYZ | 9 | 9 | 9 |
| EPG | EPG | -/-- GUIDE | Guide |
| TEXT | Text | REPEAT TEXT | Text |
| FAV | FAV | SHIFT + FAV PRE-CH | Shift + Pre Ch |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| SLEEP | Sleep | PROG SLEEP | Sleep | | |
| SUBTITLE | Subtitle | AD SUBT | Subt | | |
| LANG | Lang | SOUND DUAL | Dual | | |
| SCREEN | Screen | PICTURE FORMAT | Format | | |
| PRESETS | Presets | ZOOM ⏏ | Eject | | |
| INTERNET | Internet | HOME SMART | Smart | | |
| MULTIMEDIA | Multimedia | APP MEDIA | Media | | |
| ▶ | Play | PLAY MODE ▶ | Play | | |
| MY BUTTON 1 | My Button1 | DISC NAV LIST | List | | |
| MY BUTTON 2 | My Button2 | E-MANUAL D.MENU | D. Menu | | |
| ● | Rec | REC MODE ● | Rec | | |
| ❚❚ | Pause | ❚❚ | Pause | | |
| ■ | Stop | ■ | Stop | | |
| ▶▶ | >> | ≫ | >> | | |
| ◀◀ | << | ≪ | << | | |
| ▶▶❚ | >>I | ≫❚ | >>I | | |
| ❚◀◀ | I << | ❚≪ | I << | | |