Original		Replacement	
	Power		Power
TV	TV	PROGRAM TV/RADIO	TV/Radio /
TV	TV	SHIFT + TV 1	Shift + 1
AV	AV	RDS AV INPUT	AV / Input / RDS
R	R	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
R	R	SHIFT + TUNER 6	Shift + 6
F1	F1	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
F2	F2	SHIFT + APP REPEAT	Shift + Green / APP /
F3	F3	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8

Original		Replacement	
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
P+	P+	+ CH PAGE	CH+ / Page+
P+	Up		Up
	White	PC FAV MARKER	Fav / Marker / PC
	Left		Left
OK	OK	OK	OK
	Right		Right
	Green	APP REPEAT	Green / APP / Repeat
P-	Down		Down
P-	P-	CH PAGE −	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
INFO	Info	ANGLE INFO	Info / Angle

Original		Replacement	
II	Pause	STEP-FREEZE II	Pause / Step / Freeze
🔇	Mute	DIMMER MUTE	Mute / Dimmer
TEXT	Text	GOTO TEXT	Text / Goto
MENU	Menu	HOME MENU	Menu / Home

Original	Replacement

Original		Replacement	
	Power		Power
	TV	SHIFT + TV 1	Shift + 1
	TV	PROGRAM TV/RADIO	TV/Radio /
	AV	RDS AV INPUT	AV / Input / RDS
	R	SHIFT + TUNER 6	Shift + 6
	R	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
	F1	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
	F2	SHIFT + APP REPEAT	Shift + Green / APP /
	F3	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX-HDD 7	7
	8	USB 8	8

Original		Replacement	
	9	BLUETOOTH 9	9
	0	HDMI-SAT 0	0
	Blue/Picture	FORMAT PICTURE	Picture / Format
	Blue/Picture	Prime Video RANDOM	Blue / Prime Video / Random
	Yellow/Sound	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Yellow/Sound	TITLE SOUND	Sound / Title
	P+	CH PAGE +	CH+ / Page+
	Up		Up
	White	PC FAV MARKER	Fav / Marker / PC
	Left		Left
	OK	OK	OK
	Right		Right
	Green/Timer	APP REPEAT	Green / APP / Repeat
	Green/Timer	TIMER SLEEP	Sleep / Timer
	P-	CH PAGE −	CH- / Page-
	Down		Down
	Red/Recall	NETFLIX SEARCH	Red / Netflix / Search

Original	Replacement	Original	Replacement
Red/ Recall	Back / Return		
Vol +	Vol +		
Vol -	Vol -		
Info	Info / Angle		
Pause	Pause / Step / Freeze		
Mute	Mute / Dimmer		
Text	Text / Goto		
Menu	Menu / Home		