Original	Replacement	Original	Replacement
Power Receiver	Power	2 Receiver	2
Enter Receiver	Ok	3 Receiver	3
Up Receiver	Up	4 Receiver	4
Down Receiver	Down	5 Receiver	5
Right Receiver	Right	6 Receiver	6
Left Receiver	Left	7 Receiver	7
Return Receiver	Back	8 Receiver	8
Q/Setup Receiver	Smart	9 Receiver	9
Home/Audio	Media	0/11 Receiver	0
Play Receiver	Play	+10/--/--10/Dimmer/D.Tun Receiver	Shift + Guide
I<< Receiver	I<<	CLR/Sleep/12 Receiver	Pre Ch
>>I Receiver	>>I	Movie Tv/Red/Search	Red
<< Receiver	<<	Music/Green/Repeat Receiver	Green
>> Receiver	>>	Game/Yellow/Random Receiver	Yellow
Pause Receiver	Pause	Stereo/Blue/Mode Receiver	Blue
Stop Receiver	Stop	Vol + Receiver	Vol +
1 Receiver	1	Vol - Receiver	Vol -

Original		Replacement	
CH DISC	CH Disc/Album+ Receiver	CH +	Ch +
ALBUM	CH Disc/Album- Receiver	CH -	Ch -
TV	Power Tv	SHIFT +	Shift + Power
TV INPUT	Input Tv	TIMER AV	AV
CH DISC	CH+ Tv	SHIFT + CH +	Shift + Ch +
ALBUM	CH- Tv	SHIFT + CH -	Shift + Ch -
	Up Tv	SHIFT +	Shift + Up
ENTER	Enter Tv	SHIFT + OK	Shift + Ok
	Down Tv	SHIFT +	Shift + Down
	Right Tv	SHIFT +	Shift + Right
	Left Tv	SHIFT +	Shift + Left
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide	SHIFT + TOP MENU MENU	Shift + Menu
RETURN	Return Tv	SHIFT + RETURN BACK	Shift + Back
Q SETUP	Q/Setup Tv	SHIFT + HOME SMART	Shift + Smart
SEARCH MOVIE/TV A	Red Tv	SETTINGS OPT	Options
REPEAT MUSIC B	Green Tv	SOUND DUAL	Dual

Original		Replacement	
RANDOM GAME C	Yellow Tv	AD SUBT	Subt
MODE STEREO D	Blue Tv	SEARCH TV/R	TV/R
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
11 0	0/11 Tv	SHIFT + 0	Shift + 0
D.TUN DIMMER	+10/--/--10 Tv	GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	SHIFT + FAV PRE-CH	Shift + Pre Ch
VOL	Vol + Tv	SHIFT + SOUND DUAL	Shift + Dual
VOL	Vol - Tv	SHIFT + SETTINGS OPT	Shift + Options
AUX	AUX	REPEAT TEXT	Text

Original		Replacement		Original	Replacement
TV/CD	TV/ CD	PICTURE FORMAT	For mat		
CBL/SAT	CBL/ SAT	ECO 3D	3D		
FM	FM	SHIFT + AD SUBT	Shi f t + Subt		
NET	NET	SHIFT + APP MEDIA	Shi f t + Medi a		
PC	PC	SHIFT + SEARCH TV/R	Shi f t + TV/ R		
BD/DVD	BD/ DVD	SHIFT + REPEAT TEXT	Shi f t + Text		
USB	USB	SHIFT + TIMER AV	Shi f t + AV		

Original		Replacement	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Q/Setup	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
	Right BD/DVD		Right
	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
PLAY	Play BD/DVD	PLAY MODE	Play
	Pause BD/DVD		Pause

Original		Replacement	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat BD/DVD	B	Green
RANDOM GAME C	Game/Yellow/Random BD/DVD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
-/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer BD/DVD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

Original		Replacement		Original		Replacement	
CBL/SAT	CBL/ SAT	REPEAT TEXT	Text	<<	<< CBL/ SAT	SHIFT + CH −	Shift + Ch -
VOL +	Vol + Recei ver	+ VOL	Vol +	>>	>> CBL/ SAT	SHIFT + + CH	Shift + Ch +
VOL −	Vol - Recei ver	VOL −	Vol -	PLAY	Pl ay CBL/ SAT	ECO 3D	3D
SOURCE	Power CBL/ SAT	SHIFT +	Shi ft + Power	SEARCH MOVIE/TV A	Movi e Tv/ Red/ Search	SOUND DUAL	Dual
CH DISC +	CH Di sc/ Al bum+ CBL/ SAT	+ CH	Ch +	REPEAT MUSIC B	Musi c/ Green/ Repe at CBL/ SAT	AD SUBT	Subt
ALBUM −	CH Di sc/ Al bum- CBL/ SAT	CH −	Ch -	RANDOM GAME C	Game/ Yel l ow/ Ran dom CBL/ SAT	TIMER AV	AV
MENU PREV CH	Menu/ Pr ev CH CBL/ SAT	SHIFT + TOP MENU MENU	Shi ft + Menu	MODE STEREO D	St ereo/ Bl ue/ Mode CBL/ SAT	PICTURE FORMAT	For mat
TOP MENU GUIDE	Top Menu/ Gui de CBL/ SAT	SHIFT + SETTINGS OPT	Shi ft + Opti ons	1	1 CBL/ SAT	SHIFT + 1	Shi ft + 1
RETURN	Ret ur n CBL/ SAT	SHIFT + RETURN BACK	Shi ft + Back	2	2 CBL/ SAT	SHIFT + 2	Shi ft + 2
Q SETUP	Q/ Set up	SHIFT + HOME SMART	Shi ft + Smart	3	3 CBL/ SAT	SHIFT + 3	Shi ft + 3
	Up CBL/ SAT	SHIFT + ▲	Shi ft + Up	4	4 CBL/ SAT	SHIFT + 4	Shi ft + 4
ENTER	Ent er CBL/ SAT	SHIFT + OK	Shi ft + Ok	5	5 CBL/ SAT	SHIFT + 5	Shi ft + 5
	Down CBL/ SAT	SHIFT + ▼	Shi ft + Down	6	6 CBL/ SAT	SHIFT + 6	Shi ft + 6
	Ri ght CBL/ SAT	SHIFT + ▶	Shi ft + Ri ght	7	7 CBL/ SAT	SHIFT + 7	Shi ft + 7
	Left CBL/ SAT	SHIFT + ◀	Shi ft + Left	8	8 CBL/ SAT	SHIFT + 8	Shi ft + 8
II	Pause CBL/ SAT	SHIFT + II	Shi ft + Pause	9	9 CBL/ SAT	SHIFT + 9	Shi ft + 9
■	St op CBL/ SAT	SHIFT + ■	Shi ft + St op	0 11	0/ 11 CBL/ SAT	SHIFT + 0	Shi ft + 0

Original	Replacement	Original	Replacement
BD/DVD BD/ DVD	SEARCH TV/R TV/ R		

Original		Replacement	
SOURCE	Power TV/CD		Power
CH DISC	CH/Disc+ TV/CD	CH	Ch +
ALBUM	CH/Disc TV/CD	CH	Ch -
RETURN	Return TV/CD	RETURN BACK	Back
Q SETUP	Q/Setup TV/CD	HOME SMART	Smart
AUDIO HOME	Home/Audio	APP MEDIA	Media
	Up TV/CD		Up
	Down TV/CD		Down
	Right TV/CD		Right
	Left TV/CD		Left
ENTER	Enter TV/CD	OK	Ok
	I<< TV/CD		I<<
	>>I TV/CD		>>I
	<< TV/CD		<<
	>> TV/CD		>>
PLAY	Play TV/CD	PLAY MODE	Play
	Pause TV/CD		Pause

Original		Replacement	
	Stop TV/CD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat TV/CD	B	Green
RANDOM GAME C	Game/Yellow/Random TV/CD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode TV/CD	D	Blue
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9
11 0	0/11 TV/CD	0	0
-/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer TV/CD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

Original		Replacement		Original		Replacement	
VOL	Vol + Recei ver	+ VOL	Vol +				
VOL	Vol - Recei ver	VOL −	Vol -				
TV/CD	TV/ CD	SEARCH TV/R	TV/ R				

Original		Replacement	
RECEIVER	Power Receiver Zone 2		Power
VOL	Vol + Zone 2	VOL	Vol +
VOL	Vol - Zone 2	VOL	Vol -
CH DISC	CH Disc/Album+ Zone 2	CH	Ch +
ALBUM	CH Disc/Album- Zone 2	CH	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
	Right Zone 2		Right
	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
Q SETUP	Q/Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Home/Audio Zone	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
PLAY	Play Zone 2	PLAY MODE	Play
	>> Zone 2		>>

Original		Replacement	
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat Zone 2	B	Green
RANDOM GAME C	Game/Yellow/Random Zone 2	C	Yellow
MODE STEREO D	Stereo/Blue/Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9
0 11	0/11 Zone 2	0	0

Original		Replacement		Original		Replacement	
	+10/ - - / - - 10/ D. Tu Di mmer Zone 2		Gui de				
	CLR/ Sl eep/ 12		Pr e Ch				