Original	Replacement
On / Standby	Power
Display	Info
Input BD/DVD	Shift + 1
Input VCR/DVR	Shift + 2
Input CBL/SAT	Shift + 3
Input Game	Shift + 4
Input AUX	Shift + 5
Input Tuner	Shift + 6
Input TV/CD	Shift + 7
Input Port	Shift + 8
Tone	Shift + Ok
Tone +	Shift + Up
Tone -	Shift + Down
Tun Mode	Smart
Muting	Mute
CH +	Ch +
CH -	Ch -

Original	Replacement
Vol +	Vol +
Vol -	Vol -
Guide / Top Menu	D. Menu
Guide / Top Menu	Shift + Menu
Guide / Top Menu	Guide
Prev CH / Menu	Menu
Prev CH / Menu	Pre Ch
Up	Up
Left / Playlist/Category	Left
Enter	Ok
Right / Playlist/Category	Right
Down	Down
Setup	Options
Audio	Dual
Return	Back
I <<	I <<
>>I	>>I

Original		Replacement	
	<<		<<
	Play	PLAY MODE	Play
	>>		>>
	Pause / Play Reverse		Pause
	Stop		Stop
MOVIE/TV SEARCH	Movie/TV / Search	A	Red
MOVIE/TV SEARCH	Movie/TV / Search	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat	B	Green
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play	D	Blue
STEREO PLAY MODE	Stereo / Play	SHIFT + PLAY MODE	Shift + Play
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5

Original		Replacement	
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10 D.TUN DIMMER	+10 / Dimmer	SHIFT + GUIDE	Shift + Guide
+10 D.TUN DIMMER	D.Tun Tuner	APP MEDIA	Media
CLR SLEEP	Clear / Sleep	CLEAR EXIT	Exit
CLR SLEEP	Clear / Sleep	PROG SLEEP	Sleep

Original		Replacement	
ON/STANDBY	On/Standby		Power
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3
GAME	Input Game	SHIFT + 4	Shift + 4
AUX	Input AUX	SHIFT + 5	Shift + 5
TUNER	Input Tuner	SHIFT + 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7
PORT	Input Port	SHIFT + 8	Shift + 8
TONE	Tone	SHIFT + OK	Shift + Ok
+	Tone +	SHIFT + ▲	Shift + Up
−	Tone -	SHIFT + ▼	Shift + Down
TUN MODE	Tun Mode	HOME SMART	Smart
MUTING	Muting	MUTE	Mute
VOL ▲	Vol +	+ VOL	Vol +
VOL ▼	Vol -	VOL −	Vol -
ON/STANDBY	On/Standby	SHIFT + ⏻	Shift + Power

Original		Replacement	
DISPLAY	Display BD/DVD	DISPLAY INFO	Info
GUIDE/TOP MENU SP A/B	Guide / Top Menu BD/DVD	SHIFT + TOP MENU MENU	Shift + Menu
GUIDE/TOP MENU SP A/B	Guide / Top Menu BD/DVD	E-MANUAL D.MENU	D. Menu
GUIDE/TOP MENU SP A/B	Guide / Top Menu BD/DVD	-/-- GUIDE	Guide
PREV CH/MENU	Prev CH / Menu BD/DVD	TOP MENU MENU	Menu
PREV CH/MENU	Prev CH / Menu BD/DVD	FAV PRE-CH	Pre Ch
	Up BD/DVD	▲	Up
PLAYLIST /CATEGORY	Left / Playlist/Category	◀	Left
ENTER	Enter BD/DVD	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Category	▶	Right
	Down BD/DVD	▼	Down
SETUP	Setup BD/DVD	SETTINGS OPT	Options
AUDIO	Audio BD/DVD	SOUND DUAL	Dual
RETURN	Return BD/DVD	RETURN BACK	Back
⏮	I<< BD/DVD	⏮	I<<
⏭	>>I BD/DVD	⏭	>>I
⏪	<< BD/DVD	⏪	<<

Original	Replacement
Play BD/DVD	PLAY MODE ▶ Play
>> BD/DVD	>> >>
Pause BD/DVD	II Pause
Stop BD/DVD	■ Stop
MOVIE/TV SEARCH Movie/TV / Search BD/DVD	A Red
MOVIE/TV SEARCH Movie/TV / Search BD/DVD	SEARCH TV/R TV/R
MUSIC REPEAT Music / Repeat BD/DVD	B Green
MUSIC REPEAT Music / Repeat BD/DVD	REPEAT TEXT Text
GAME RANDOM Game / Random BD/DVD	C Yellow
STEREO PLAY MODE Stereo / Play Mode BD/DVD	D Blue
STEREO PLAY MODE Stereo / Play Mode BD/DVD	SHIFT + PLAY MODE ▶ Shift + Play
1 BD/DVD	1 1
2 BD/DVD	2 2
3 BD/DVD	3 3
4 BD/DVD	4 4
5 BD/DVD	5 5
6 BD/DVD	6 6

Original	Replacement
7 BD/DVD	7 7
8 BD/DVD	8 8
9 BD/DVD	9 9
0 BD/DVD	0 0
+10 D.TUN DIMMER +10 / Dimmer	SHIFT + GUIDE Shift + Guide
CLR SLEEP CLR / Sleep	CLEAR EXIT Exit
CLR SLEEP CLR / Sleep	PROG SLEEP Sleep

Original	Replacement
On / Standby	Power
Input BD/DVD	Shift + 1
Input VCR/DVR	Shift + 2
Input CBL/SAT	Shift + 3
Input Game	Shift + 4
Input Aux	Shift + 5
Input Tuner	Shift + 6
Input TV/CD	Shift + 7
Input Port	Shift + 8
Tone	Shift + Ok
Tone +	Shift + Up
Tone -	Shift + Down
Tun Mode	Smart
Muting	Mute
Vol +	Vol +
Vol -	Vol -
On / Standby	Shift + Power

Original	Replacement
Display TV/CD	Info
Disc + / Album + TV/CD	Ch +
Disc - / Album TV/CD	Ch -
Up TV/CD	Up
Left / Playlist/Category	Left
Enter TV/CD	Ok
Right / Playlist/Category	Right
Down TV/CD	Down
Setup TV/CD	Options
Audio TV/CD	Dual
Return TV/CD	Back
I<< TV/CD	I<<
>>I TV/CD	>>I
<< TV/CD	<<
>> TV/CD	>>
Play TV/CD	Play
Pause TV/CD	Pause

Original		Replacement	
	Stop TV/CD		Stop
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	A	Red
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat TV/CD	B	Green
MUSIC REPEAT	Music / Repeat TV/CD	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode TV/CD	D	Blue
STEREO PLAY MODE	Stereo / Play Mode TV/CD	SHIFT + PLAY MODE	Shift + Play
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9

Original		Replacement	
0	0 TV/CD	0	0
+10 D.TUN DIMMER	+10 / Dimmer	GUIDE	Guide
CLR SLEEP	CLR / Sleep TV/C	CLEAR EXIT	Exit
CLR SLEEP	CLR / Sleep TV/C	PROG SLEEP	Sleep

Original		Replacement	
ON/STANDBY	On / Standby	Power	
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3
GAME	Input Game	SHIFT + 4	Shift + 4
AUX	Input AUX	SHIFT + 5	Shift + 5
TUNER	Input Tuner	SHIFT + 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7
PORT	Input Port	SHIFT + 8	Shift + 8
TONE	Tone	SHIFT + OK	Shift + Ok
+	Tone +	SHIFT + ▲	Shift + Up
−	Tone -	SHIFT + ▼	Shift + Down
TUN MODE	Tun Mode	HOME SMART	Smart
MUTING	Muting	MUTE	Mute
VOL ▲	Vol +	+ VOL	Vol +
VOL ▼	Vol -	VOL −	Vol -
ON/STANDBY	On / Standby Por	SHIFT + ⏻	Shift + Power

Original		Replacement	
DISPLAY	Display Port	DISPLAY INFO	Info
+ CH	CH + Port	+ CH	Ch +
CH −	CH - Port	CH −	Ch -
	Up Port	▲	Up
PLAYLIST /CATEGORY	Left / Playlist/Categor	◀	Left
ENTER	Enter Port	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Categor	▶	Right
	Down Port	▼	Down
SETUP	Setup Port	SETTINGS OPT	Options
RETURN	Return Port	RETURN BACK	Back
⏮	I<< Port	⏮	I<<
⏭	>>I Port	⏭	>>I
◀◀	<< Port	◀◀	<<
▶	Play Port	PLAY MODE ▶	Play
▶▶	>> Port	▶▶	>>
⏸	Pause / Play Reverse Port	⏸	Pause
■	Stop Port	■	Stop

Original		Replacement	
MOVIE/TV SEARCH	Movie/TV / Search Port	A	Red
MOVIE/TV SEARCH	Movie/TV / Search Port	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat	B	Green
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode Port	D	Blue
STEREO PLAY MODE	Stereo / Play Mode Port	SHIFT + PLAY MODE ▶	Shift + Play
1	1 Port	1	1
2	2 Port	2	2
3	3 Port	3	3
4	4 Port	4	4
5	5 Port	5	5
6	6 Port	6	6
7	7 Port	7	7
8	8 Port	8	8
9	9 Port	9	9
0	0 Port	0	0

Original		Replacement	
+10 D.TUN DIMMER	+10 / Dimmer	GUIDE	Guide
CLR SLEEP	CLR / Sleep Port	CLEAR EXIT	Exit
CLR SLEEP	CLR / Sleep Port	PROG SLEEP	Sleep