Original	Replacement
Power Receiver	Power
1	1
VCR / DVR	Shift + 4
2	2
CBL / SAT	Shift + 0
3	3
4	4
AUX	Shift + 7
5	5
Multi CH	Shift + 1
6	6
DVD	Shift + 2
7	7
TAPE	Shift + 5
8	8
TUNER	Shift + 6
9	9

Original	Replacement
CD	Shift + 3
D. TUN	Smart / List
Dimmer	Shift + Mute / Dimmer
0	0
Sleep	Sleep / Timer
CH+	CH+ / Page+
Vol +	Vol +
CH-	CH- / Page-
Vol -	Vol -
SP A/B	Info / Angle
Up	Up
Muting	Mute / Dimmer
Left	Left
Enter	OK
Right	Right
Setup	Setup / OPT /
Down	Down

Original	Replacement	Original	Replacement
Return	Back / Return	L. Night	Menu / Home
Pause / Play Rev	Pause / Step / Freeze	Cine FLTR	D. Menu / Top
Play	Play / Slow		
Stop	Stop / Hold		
<<	<< / Tune-		
>>	>> / Tune+		
I <<	I << / Preset-		
>>I	>>I / Preset+		
Stereo	Audio / Lang I/II		
Surround	Eject / Surround		
< Listening Mode	Shift + I << / Preset-		
Listening Mode >	Shift + >>I / Preset+		
Test Tone	Red / Netflix / Search		
CH Sel	Green / APP / Repeat		
Level -	Yellow / YouTube / Repeat		
Level +	Blue / Prime Video / Random		
Display	Display / Media		

Original	Replacement	Original	Replacement
Power	Power	Left / Playlist / Ca	Left
1	1	Enter	OK
2	2	Right / Playlist / C	Right
3	3	Setup	Setup / OPT /
4	4	Down	Down
5	5	Return	Back / Return
6	6	Pause	Pause / Step / Freeze
7	7	Play	Play / Slow
8	8	Stop	Stop / Hold
9	9	<<	<< / Tune-
+10/ 10/ - / - -	Guide / EPG / - / - -	>>	>> / Tune+
0/ 11	0	I <<	I << / Preset-
CLR/ 12/ Sleep	Sleep / Timer	>>I	>>I / Preset+
CLR/ 12/ Sleep	Exit / Cancel / Clear	Stereo	Sound / Title
Guide/ Top	D. Menu / Top	Surround	Eject / Surround
Up	Up	< Listening Mode	Shift + I << / Preset-
Previous Menu/ Muting	Menu / Home	Listening Mode >	Shift + >>I / Preset+

Original		Replacement		Original	Replacement
AUDIO / TEST TONE	Audio	LANG I/II / AUDIO	Audio / Lang I/II		
SUBTITLE / CH SEL	Subtitle	EQ / SUBTITLE	Subtitle / EQ		
RANDOM / LEVEL-	Level- / Random	Prime Video / RANDOM	Blue / Prime Video / Random		
REPEAT / LEVEL+	Level+ / Repeat	APP / REPEAT	Green / APP / Repeat		
DISPLAY	Display	MEDIA / DISPLAY	Display / Media		
PLAY MODE / VCR	Play Mode VCR	SHIFT + VIDEO 4	Shift + 4		
L NIGHT / DVD	Play Mode DVD	SHIFT + DVD 2	Shift + 2		
CINE FLTR / HDD	Play Mode HDD	SHIFT + AUX-HDD 7	Shift + 7		

Original	Replacement	Original	Replacement
Power	Power	Vol -	Vol -
1	1	Pause	Pause / Step / Freeze
2	2	Play	Play / Slow
3	3	Stop	Stop / Hold
4	4	<<	<< / Tune-
5	5	>>	>> / Tune+
6	6	I <<	I << / Preset-
7	7	>>I	>>I / Preset+
8	8	Stereo	Audio / Lang I/II
9	9	Surround	Eject / Surround
+10/10/-/--	Guide / EPG / -/--	< Listening Mode	Shift + I << / Preset-
0	0	Listening Mode >	Shift + >>I / Preset+
CLR/12/Sleep	Sleep / Timer	Level-/Random	Blue / Prime Video / Random
CLR/12/Sleep	Exit / Cancel / Clear	Level+/Repeat	Green / APP / Repeat
Disc/Album	CH+ / Page+	Display	Display / Media
Vol +	Vol +		
Disc/Album CH-	CH- / Page-		

Original	Replacement	Original	Replacement
Standby / On	Power	Up	Up
VCR/DVR	4	Muting	Mute / Dimmer
CBL/SAT	0	Left/Playlist/Ca	Left
AUX	7	Enter	OK
Multi CH	1	Right/Playlist/C	Right
DVD	2	Setup	Setup / OPT /
Tape	5	Down	Down
Tuner	6	Return	Back / Return
CD	3	Rev. Play	Pause / Step / Freeze
D. Tun	Smart / List	Play	Play / Slow
Dimmer	Shift + Mute / Dimmer	Stop	Stop / Hold
CLR / Sleep	Sleep / Timer	<<	<< / Tune-
CLR / Sleep	Exit / Cancel / Clear	>>	>> / Tune+
CH Disc	CH+ / Page+	Stereo	Audio / Lang I/II
Vol +	Vol +	Surround	Eject / Surround
CH Disc Album	CH- / Page-	< Listening Mode	I << / Preset-
Vol -	Vol -	Listening Mode >	>>I / Preset+

Original		Replacement		Original	Replacement
AUDIO TEST TONE	Test Tone	NETFLIX SEARCH	Red / Netflix / Search		
SUBTITLE CH SEL	CH Sel	APP REPEAT	Green / APP / Repeat		
RANDOM LEVEL-	Level -	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
REPEAT LEVEL+	Level +	Prime Video RANDOM	Blue / Prime Video / Random		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		
L NIGHT DVD	L. Night / Play Mode DVD	HOME MENU	Menu / Home		
CINE FLTR HDD	Cine FLTR / Play Mode HDD	TOP MENU D.MENU	D. Menu / Top		