Original		Replacement	
ON/STANDBY	On / Standby		Power
1 V1	Input Selector V	TV 1	1
2 V2	Input Selector V	VIDEO 4	4
3 V3	Input Selector V	AUX - HDD 7	7
0 11 DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
5 MULTI CH	Input Selector Multi CH	USB 8	8
RETURN	Return	RETURN BACK	Back / Return
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
ENTER	Enter	OK	OK
6 DVD	Input Selector	DVD 2	2
7 TAPE	Input Selector	TAPE 5	5
CLR 12 SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
8 TUNER	Input Selector Tuner	TUNER 6	6
GUIDE TOP MENU SP A/B	SP A/B	LANG I/II AUDIO	Audio / Lang I/II
PREVIOUS MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	Up		Up
	Down		Down

Original		Replacement	
PLAYLIST/CAT+	Right		Right
9 CD	Input Selector C	CD - STB 3	3
-PLAYLIST/CAT	Left		Left
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	Play Rev.	STEP - FREEZE	Pause / Step / Freeze
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
DISPLAY	Display	MEDIA DISPLAY	Display / Media
STEREO	Listening Mode Stereo	TITLE SOUND	Sound / Title
SURROUND	Listening Mode Surround	SURROUND	Eject / Surround
MODE	Listening Mode <	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
AUDIO TEST TONE	Test Tone	GOTO TEXT	Text / Goto
RANDOM LEVEL-	Level -	CH PAGE	CH- / Page-

Original	Replacement	Original	Replacement
Vol +	Vol +	5 Tv	Shift + 5
CH Sel	Smart / List	7 Tv	Shift + 7
Level +	CH+ / Page+	8 Tv	Shift + 8
L. Night	TV/ Radio /	9 Tv	Shift + 9
Cine FLTR	D. Menu / Top	0 Tv	Shift + 0
Vol -	Vol -	+10 Tv	Shift + Guide / EPG / -/--
Input Tv	Shift + AV / Input / RDS	Enter Tv	Shift + OK
Vol + Tv	Shift + Vol +	Right Tv	Shift + Right
Vol - Tv	Shift + Vol -	Previous Menu Tv	Shift + Fav / Marker / PC
CH/ Disc/ Album	Shift + CH+ /	Left Tv	Shift + Left
CH/ Disc/ Album	Shift + CH- /	Setup Tv	Shift + Setup / OPT / Tools
1 Tv	Shift + 1	Up Tv	Shift + Up
2 Tv	Shift + 2	Down Tv	Shift + Down
Power Tv/ Standby	Shift + Power		
3 Tv	Shift + 3		
4 Tv	Shift + 4		
6 Tv	Shift + 6		

Original	Replacement	Original	Replacement
Power	Power	Previous Menu/Muting	Mute / Dimmer
1	1	Left/Playlist/Ca	Left
2	2	Enter	OK
3	3	Right/Playlist/C	Right
4	4	Return	Back / Return
5	5	Down	Down
6	6	Setup	Setup / OPT /
7	7	Pause	Pause / Step / Freeze
8	8	Play	Play / Slow
9	9	Stop	Stop / Hold
VCR	SHIFT + VIDEO 4 Shift + 4	<<	<< / Tune-
+10/10/-/--	Guide / EPG / -/--	>>	>> / Tune+
0/11	0	I <<	I << / Preset-
CLR	Exit / Cancel / Clear	>>I	>>I / Preset+
Top Menu	D. Menu / Top	Stereo	Sound / Title
Up	Up	Surround	Eject / Surround
Previous Menu/Muting	Menu / Home	< Listening Mode	SHIFT + PRESET- Shift + I << / Preset-

Original	Replacement	Original	Replacement
Listening Mode >	SHIFT + PRESET+ Shift + >>I / Preset+		
Audio	LANG I/II AUDIO Audio / Lang I/II		
Subtitle	EQ SUBTITLE Subtitle / EQ		
Random	Prime Video RANDOM Blue / Prime Video / Random		
Repeat	APP REPEAT Green / APP / Repeat		
Display	MEDIA DISPLAY Display / Media		
Play Mode VCR	FORMAT PICTURE Picture / Format		
DVD	SHIFT + DVD 2 Shift + 2		
HDD	SHIFT + AUX-HDD 7 Shift + 7		

Original	Replacement	Original	Replacement
On / Standby	Power	Pause	Pause / Step / Freeze
1	1	Play	Play / Slow
2	2	Stop	Stop / Hold
3	3	<<	<< / Tune-
4	4	>>	>> / Tune+
5	5	I <<	I << / Preset-
6	6	>>I	>>I / Preset+
7	7	Stereo	Audio / Lang I/II
8	8	Surround	Eject / Surround
9	9	< Listening Mode	Shift + I << / Preset-
+10/10/-/--	Guide / EPG / -/--	Listening Mode >	Shift + >>I / Preset+
0/11	0	Random	Blue / Prime Video / Random
12	Fav / Marker / PC	Repeat	Green / APP / Repeat
Disc+	CH+ / Page+	Display	Display / Media
Vol +	Vol +		
Disc-	CH- / Page-		
Vol -	Vol -		

Original	Replacement	Original	Replacement
Power	Power	<<	<< / Tune-
1	1	Stereo	Audio / Lang I/II
2	2	Surround	Eject / Surround
3	3	< Listening Mode	Shift + I << / Preset-
4	4	Listening Mode >	Shift + >>I / Preset+
5	5	Play Mode	D. Menu / Top
6	6	L. Night	Sleep / Timer
7	7		
8	8		
9	9		
+10/ 10/ - / - -	Guide / EPG / - / - -		
0/ 11	0		
CH+	CH+ / Page+		
CH-	CH- / Page-		
Pause	Pause / Step / Freeze		
Play	Play / Slow		
Stop	Stop / Hold		