Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	+10	GUIDE	Guide
	Repeat	TEXT	Text
	FL Display	INFO	Info
	Manual Skip	SUBT	Subt
	Play Mode	TV/R	TV/R
	Quick OSD	PRE-CH	Pre Ch

Original		Replacement	
	Play		Play
	Pause		Pause
	Stop		Stop
	<< Slow/Search		<<
	Slow/Search >>		>>
	I<<<CH-		I<<
	>>I/CH+		>>I
	Menu/Play List		Menu
	Top Menu/Direct Navigator		Smart
	Return		Back
	Functions		Options
	Enter		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Muting		Mute

Original		Replacement	
+	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
SUBWOOFER LEVEL	Subwoofer	SOUND DUAL	Dual
SFC	SFC	TIMER AV	AV
C.FOCUS	C. Focus	ECO 3D	3D
MIX2CH DD PL II	DD PL II	PICTURE FORMAT	Format
TV/VCR	TV/VCR	A	Red
TUNER/BAND	Tuner/Band	B	Green
DVD/CD	DVD/CD	C	Yellow
SLEEP TV/AV	TV/AV	DISC NAV LIST	List
ADVANCED DISC REVIEW	Advanced Disc Review	APP MEDIA	Media
PLAY SPEED QUICK REPLAY	Quick Replay	CLEAR EXIT	Exit
SLEEP TV/AV	Sleep	PROG SLEEP	Sleep
PLAY SPEED QUICK REPLAY	Play Speed	SHIFT + HOME SMART	Shift + Smart
CANCEL	Cancel	E-MANUAL D.MENU	D. Menu
MIX2CH DD PL II	Mix2CH	SHIFT + PICTURE FORMAT	Shift + Format
SETUP FUNCTIONS	Setup	SHIFT + AD SUBT	Shift + Subt

Original		Replacement	
V ⏮	TV CH-	CH –	Ch -
H ⏭	TV CH+	+ CH	Ch +
+	TV Vol +	SHIFT + ▶	Shift + Right
–	TV Vol -	SHIFT + ◀	Shift + Left
AUDIO 1	Audio	SHIFT + SOUND DUAL	Shift + Dual
CH SELECT 2	CH Select	SHIFT + 2	Shift + 2
TEST 3	Test	SHIFT + 3	Shift + 3
GROUP 4	Group	SHIFT + 4	Shift + 4
SUBTITLE 5	Subtitle	SHIFT + ZOOM ⏏	Shift + Eject
ZOOM 6	Zoom	ZOOM ⏏	Eject
PROGRESSIVE 7	Progressive	SHIFT + 7	Shift + 7
ANGLE/PAGE 9	Angle/Page	SHIFT + 9	Shift + 9