Original		Replacement	
	Power		Power
	Open/Close	ZOOM	Eject
AUDIO SOURCE	Source/Audio	TIMER AV	AV
RADIO	Radio	SEARCH TV/R	TV/R
USB	USB	APP MEDIA	Media
PROGRAM REPEAT	Repeat/Program	REPEAT TEXT	Text
DISC	Disc	HOME SMART	Smart
SETUP	[≡]/Setup	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right/>>		Right
	<<Left		Left
OK	OK	OK	Ok
BACK	Back	RETURN BACK	Back
INFO	[i]/Info	DISPLAY INFO	Info
	Play	PLAY MODE	Play
	Pause		Pause

Original		Replacement	
	I<		I<<
	>I		>>I
	Stop		Stop
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
	Mute	MUTE	Mute
SOUND	Sound	SOUND DUAL	Dual
SURR	Surr	+ CH	Ch +
AUDIO SYNC	Audio Sync	CH –	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8

Original		Replacement	
9	9	9	9
0	0	0	0
ZOOM/ CREATE MP3	Zoom/Create	PICTURE FORMAT	Format
SUBTITLE	Subtitle	AD SUBT	Subt
VOCAL	Vocal	SETTINGS OPT	Options
VOL+	MIC Vol +	»	>>
VOL–	MIC Vol -	«	<<
KARAOKE	Karaoke	-/-- GUIDE	Guide

Original	Replacement