Original		Replacement	
	Power		Power
	TV / Video		TV/R
	DVD		Smart
	VCR		Media
	Open / Close		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Display		Info
	Up		Up

Original		Replacement	
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Stop		Stop
	Play		Play
	Pause / Step		Pause
	<< REW		<<
	>> FWD		>>
	Record		Rec
	Clear		Exit

Original	Replacement	Original	Replacement
Power	Power	System Menu	Menu
Open / Close	Eject	Up	Up
DVD	Smart	Left	Left
VCR	Media	OK	Ok
1	1	Right	Right
2	2	Down	Down
3	3	I <	I <<
4	4	>I	>>I
5	5	Stop	Stop
6	6	Play	Play
7	7	Pause / Step	Pause
8	8	<< REW	<<
9	9	>> FWD	>>
0	0	Thumbnail	3D
Return	Back	Chapter	Format
Display	Info	Timer	AV
List / Disc Men	D. Menu	Record	Rec

Original	Replacement	Original	Replacement
Rec. Mode	Blue		
Repeat	Text		
Title	Options		
Audio	Dual		
Zoom	Shift + Eject		
Search	TV/R		
Marker	Pre Ch		
D. Dubbing	Guide		
Clear	Exit		
Showview / VideoPlus+	Subt		