Original		Replacement	
STANDBY/ON	Standby/On		Power
CONTINUED	Continued	ECO 3D	3D
OPEN/CLOSE	Open/Close	ZOOM	Eject
SECONDARY VIDEO	Secondary	PICTURE FORMAT	Format
KEY LOCK	Keylock	PROG SLEEP	Sleep
REPEAT	Repeat	REPEAT TEXT	Text
REPEAT OFF	Repeat Off	DISC NAV LIST	List
EXIT	Exit	CLEAR EXIT	Exit
DISPLAY	Display	DISPLAY INFO	Info
PAGE +	Page+	+ CH	Ch +
−	Page-	CH −	Ch -
FUNCTION	Function	E-MANUAL D.MENU	D. Menu
DISC NAVIGATOR TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
POPUP MENU MENU	Menu/PopUp	TOP MENU MENU	Menu
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok

Original		Replacement	
	Right		Right
	Down		Down
HOME MENU	Home Menu	HOME SMART	Smart
RETURN	Return	RETURN BACK	Back
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
REV	<<	<<	<<
PLAY	Play	PLAY MODE	Play
FWD	>>	>>	>>
I<<	I <<	I<<	I <<
PAUSE	Pause	II	Pause
STOP	Stop	■	Stop
I>/II>	>>I / I>/II >	>>I	>>I
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt

Original		Replacement		Original	Replacement
ANGLE	Angle	SEARCH TV/R	TV/R		
FRONT LIGHT	Front Light	REC MODE	Rec		
1	1	1	1		
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0	0	0	0		
CLEAR	Clear	SHIFT + CLEAR EXIT	Shift + Exit		
ENTER	Enter	SHIFT + OK	Shift + Ok		
REPLAY	Replay	FAV PRE-CH	Pre Ch		
SKIP SEARCH	·→/Skip Search	TIMER AV	AV		
VIDEO OUTPUT RESET	Video Output Preset	APP MEDIA	Media		

Original		Replacement		Original		Replacement	
	Power Tv Control		Power				
	Input Select Tv Control		AV				
	CH+ Tv Control		Ch +				
	CH- Tv Control		Ch -				
	Vol + Tv Control		Vol +				
	Vol - Tv Control		Vol -				
	Power Receiver		Shift + Power				
	BD		Smart				
	Input → Receiver Control		Right				
	Input ← Receiver Control		Left				
	Vol + Receiver Control		Shift + Vol +				
	Vol - Receiver Control		Shift + Vol -				