Mandis shop

# Samsung BN5901259B

| Original | Replacement |
|---|---|
| Power | Power |
| OK | OK |
| Up | UP |
| Down | DOWN |
| Right | RIGHT |
| Left | LEFT |
| Return | BACK |
| Play | Play |
| Pause | Pause |
| Extra | MEDIA |
| Mute | MUTE |
| Vol+ | VOL + |
| Vol- | VOL - |
| Guide | -/-- / EPG |
| CH+ | CH + |
| CH- | CH - |
| Home | VOD |

| Original | Replacement |
|---|---|
| Source | SRC |
| TTX/MIX | TEXT |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| PRE-CH | P/C / FAV |
| Exit | EXIT |
| Info | INFO |
| Menu | MENU |
| Red | Red (A) |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Green | Green (B) | | |
| Yellow | Yellow (C) | | |
| Blue | Blue (D) | | |
| 123 | TV/R | | |
| Tools | OPT+ | | |
| Stop | Stop | | |
| Rec | Rec | | |
| <<\|<< | Rewind | | |
| >>/>>\| | Fast Forward | | |
| CH List | WIDE | | |
| AD/Subt. | Subt. | | |
| E-Manual | Audio | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |