Original		Replacement	
	Power		Power
SOURCE	Source	TIMER AV	AV
HDMI	HDMI	ECO 3D	3D
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -

Original		Replacement	
MUTE	Mute	MUTE	Mute
CH LIST	CH List	DISC NAV LIST	List
P	PR+	+ CH	Ch +
P	PR-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
	Media. P	HOME SMART	Smart
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
▲	Up	▲	Up
▶	Right	▶	Right
▼	Down	▼	Down
◀	Left	◀	Left
	Enter	OK	Ok
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
A	Red/A	A	Red

Original		Replacement		Original	Replacement
B	Green/B	B	Green		
C	Yellow/C	C	Yellow		
D	Blue/D	D	Blue		
Family Story	Family Story	APP MEDIA	Media		
SEARCH	Search	SEARCH TV/R	TV/R		
DUAL I-II	Dual I/II	SOUND DUAL	Dual		
SUPPORT	Support	PROG SLEEP	Sleep		
P.SIZE	P.Size	PICTURE FORMAT	Format		
AD/SUBT.	AD/Subt	AD SUBT	Subt		
<<	<<	<<	<<		
I<<	I<<	I<<	I<<		
Pause	Pause	Pause	Pause		
>>	>>	>>	>>		
>>I	>>I	>>I	>>I		
Rec	Rec	REC MODE	Rec		
Play	Play	PLAY MODE	Play		
Stop	Stop	Stop	Stop		