Original		Replacement	
POWER	Power		Power
FUNCTION TV SOURCE	Function Tv	RDS AV INPUT	AV / Input / RDS
	Eject	SURROUND	Eject / Surround
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
RDS DISPLAY 1	1/ RDS Display	TV 1	1
2	2	DVD 2	2
TA 3	3/ TA	CD-STB 3	3
PTY– 4	4/ PTY-	VIDEO 4	4
PTY SEARCH 5	5/ PTY Search	TAPE 5	5
PTY+ 6	6/ PTY+	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PL II	PL II	LANG I/II AUDIO	Audio / Lang I/II
0	0	HDMI-SAT 0	0
DSP/EQ	DSP/ EQ	EQ SUBTITLE	Subtitle / EQ
	I<<	PRESET-	I<< / Preset-

Original		Replacement	
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
VOL	Vol +	VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TUNING / CH	Tuning/ CH+	SHIFT + TUNE+	Shift + >> /
TUNING / CH	Tuning/ CH+	CH PAGE	CH+ / Page+
VOL	Vol -	VOL	Vol -
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
TUNING / CH	Tuning/ CH-	CH PAGE	CH- / Page-
TUNING / CH	Tuning/ CH-	SHIFT + TUNE-	Shift + << /
DISC MENU	Disc Menu	TOP MENU D.MENU	D. Menu / Top
MENU	Menu	HOME MENU	Menu / Home
TITLE MENU	Title Menu	TITLE SOUND	Sound / Title

Original		Replacement		Original		Replacement	
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /				
▲	Up	▲	Up				
INFO i	Info	ANGLE INFO	Info / Angle				
◀	Left	◀	Left				
⏎	Enter	OK	OK				
▶	Right	▶	Right				
RETURN	Return	RETURN BACK	Back / Return				
▼	Down	▼	Down				
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
A	Red	NETFLIX SEARCH	Red / Netflix / Search				
TUNER MEMORY B	Green/Tuner	APP REPEAT	Green / APP / Repeat				
MO/ST C	Yellow/MO/ST	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
CD RIPPING D	Blue/CD Ripping	Prime Video RANDOM	Blue / Prime Video / Random				
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer				
S.VOL	S. Vol	LIST SMART	Smart / List				
AUDIO UPSCALE P.BASS	P. Bass/Audio Upscale	MEDIA DISPLAY	Display / Media				

Original		Replacement	
POWER	Power		Power
FUNCTION TV SOURCE	Function Tv	RDS AV INPUT	AV / Input / RDS
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
RDS DISPLAY 1	1	TV 1	1
2	2	DVD 2	2
TA 3	3	CD-STB 3	3
PTY− 4	4	VIDEO 4	4
PTY SEARCH 5	5	TAPE 5	5
PTY+ 6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
<<	<<	TUNE− <<	<< / Tune-
>>	>>	TUNE+ >>	>> / Tune+
■	Stop	HOLD ■	Stop / Hold
▶	Play	SLOW ▶	Play / Slow

Original		Replacement	
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
+ VOL	Vol +	+ VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TUNING / CH	CH+	+ CH PAGE	CH+ / Page+
VOL −	Vol -	VOL −	Vol -
TUNING / CH	CH-	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
▲	Up	▲	Up
INFO i	Info	ANGLE INFO	Info / Angle
◀	Left	◀	Left
↵	Enter	OK	OK
▶	Right	▶	Right
RETURN	Return	RETURN BACK	Back / Return
▼	Down	▼	Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
A	Red	NETFLIX SEARCH	Red / Netflix / Search

Original		Replacement		Original		Replacement	
TUNER MEMORY B	Green	APP REPEAT	Green / APP / Repeat				
MO/ST C	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
CD RIPPING D	Blue	Prime Video RANDOM	Blue / Prime Video / Random				