Original		Replacement	
	Power		Power
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
HDMI	HDMI	SHIFT + HDMI - SAT 0	Shift + 0
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
–	--	SIZE ZOOM	Zoom / Size
PRE-CH	PRE-CH	PC FAV MARKER	Fav / Marker / PC
VOL +	Vol +	VOL +	Vol +
VOL –	Vol -	VOL –	Vol -

Original		Replacement	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CH LIST	CH List	SHIFT + LIST SMART	Shift + Smart / List
	Smart Hub	LIST SMART	Smart / List
MENU	Menu	HOME MENU	Menu / Home
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
INFO	Info	ANGLE INFO	Info / Angle
RETURN	Return	RETURN BACK	Back / Return
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▲	Up	▲	Up
	Enter	OK	OK
▼	Down	▼	Down
►	Right	►	Right
◄	Left	◄	Left
A	Red	NETFLIX SEARCH	Red / Netflix / Search
B	Green	APP REPEAT	Green / APP / Repeat
C	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Original		Replacement		Original		Replacement	
D	Blue	Prime Video / RANDOM	Blue / Prime Video / Random				
Family Story	Family Story	GOTO / TEXT	Text / Goto				
SEARCH	Search	SHIFT +	NETFLIX / SEARCH — Shift + Red / Netflix /				
MTS	MTS	EQ / SUBTITLE	Subtitle / EQ				
P.SIZE	P. Size	FORMAT / PICTURE	Picture / Format				
SUPPORT	Support	LANG I/II / AUDIO	Audio / Lang I/II				
CC	CC	PROGRAM / TV/ RADIO	TV/ Radio /				
◀◀	<<	TUNE- / ◀◀	<< / Tune-				
❚❚	Pause	STEP-FREEZE / ❚❚	Pause / Step / Freeze				
▶▶	>>	TUNE+ / ▶▶	>> / Tune+				
●	Rec	REC MODE / ●	Rec / Rec Mode				
▶	Play	SLOW / ▶	Play / Slow				
■	Stop	HOLD / ■	Stop / Hold				
CH	CH+	CH PAGE +	CH+ / Page+				
CH	CH-	CH PAGE −	CH- / Page-				