| Original | Replacement |
|---|---|
| Power | Power |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| [i +] | Info |
| [ ≡] | Text |
| Google Play | Shift + Media |
| NETFLIX | Media |

| Original | Replacement |
|---|---|
| Red | Red |
| Green | Green |
| Yellow | Yellow |
| Blue | Blue |
| Guide | Guide |
| Rec List | List |
| Input | AV |
| ☼ | Menu |
| Up | Up |
| Right | Right |
| Down | Down |
| Left | Left |
| OK | Ok |
| Back | Back |
| TV | TV/R |

**Not voice control function.**

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| HOME Home | HOME SMART Smart | EXIT Exit | CLEAR EXIT Exit |
| Vol + | + VOL Vol + | | |
| Vol - | VOL − Vol - | | |
| Recall | FAV PRE-CH Pre Ch | | |
| Mute | MUTE Mute | | |
| CH+ | + CH Ch + | | |
| CH- | CH − Ch - | | |
| AUDIO Audio | SOUND DUAL Dual | | |
| [ . . . ] | AD SUBT Subt | | |
| HELP Help | E-MANUAL D.MENU D. Menu | | |
| << | << << | | |
| Play | PLAY MODE ▶ Play | | |
| >> | >> >> | | |
| REC Rec | REC MODE Rec | | |
| Pause | ❚❚ Pause | | |

**Not voice control function.**