Original		Replacement	
	Power		Power
	Input	TIMER AV	AV
DIGITAL/ ANALOG	Digital/Analog	SETTINGS OPT	Options
TV/ RADIO	Tv/Radio	SEARCH TV/R	TV/R
EXIT	Exit	CLEAR EXIT	Exit
EXT.BOX MENU	Ext.Box Menu	E-MANUAL D.MENU	D. Menu
1 ./	1	1	1
2 abc	2	2	2
3 def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6 mno	6	6	6
7 pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0 ␣	0	0	0
	[i+]/[?]	DISPLAY INFO	Info

Original		Replacement	
	[≡]	REPEAT TEXT	Text
Google Play	Google Play	APP MEDIA	Media
NETFLIX	Netflix	SHIFT + HOME SMART	Shift + Smart
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
GUIDE	Guide	-/-- GUIDE	Guide
ACTION MENU	Action Menu	TOP MENU MENU	Menu
BACK	Back	RETURN BACK	Back
APPS	APPS	SHIFT + APP MEDIA	Shift + Media
TV	TV	ECO 3D	3D
HOME	Home	HOME SMART	Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
	OK	OK	Ok
	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
	Mute	MUTE	Mute
	Recall	FAV PRE-CH	Pre Ch
PROG +	Prog+	+ CH	Ch +
–	Prog-	CH –	Ch -
	<<	<<	<<
	Play	PLAY MODE	Play
	>>	>>	>>
	I <<	I <<	I <<
	Pause	Pause	Pause
	>>I	>>I	>>I
REC	Rec	REC MODE	Rec
	Stop	Stop	Stop
TITLE LIST	Title List	DISC NAV LIST	List
AUDIO	Audio	SOUND DUAL	Dual

Original		Replacement	
	[. . .]	AD SUBT	Subt
HELP	Help	PICTURE FORMAT	Format