Mandis shop

RM-D391

Original		Replacement	
REPEAT	Repeat	REPEAT TEXT	Text
FADER	Fader	SEARCH TV/R	TV/R
CONTINUE	Continue	SOUND DUAL	Dual
SHUFFLE	Shuffle	AD SUBT	Subt
PGM	PGM	SETTINGS OPT	Options
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
10	10	0	0
>10	>10	-/-- GUIDE	Guide
	Play	PLAY MODE	Play

Original		Replacement	
	Pause		Pause
	Stop		Stop
AMS	I << AMS		I <<
AMS	AMS >>I		>>I
	<<		<<
	>>		>>

https://mandisshop.eu/Sony-1035825-replacement-remote-control-for-Sony-RM-D391-1432911.html