Mandis shop

Sony RMT-CDS11IP

| Original | | Replacement | |
|---|---|---|---|
| OFF | Off | | Power |
| MODE | Mode | PICTURE FORMAT | Format |
| RADIO BAND | Radio/Band | SEARCH TV/R | TV/R |
| AUDIO IN | Audio In | TIMER AV | AV |
| TUNE - | I<</Tune- | | I<< |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| TUNE + | >>I/Tune+ | | >>I |
| PRESET + | Preset+ | CH + | Ch + |
| PRESET - | Preset- | CH - | Ch - |
| | Up | | Up |
| | Down | | Down |
| VOL + | Vol+ | VOL + | Vol + |
| VOL - | Vol- | VOL - | Vol - |
| MENU | Menu | TOP MENU MENU | Menu |
| ENTER | Enter | OK | Ok |
| MEGA BASS | Mega Bass | HOME SMART | Smart |

| Original | | Replacement | |
|---|---|---|---|
| MEGA Xpand | Mega Xpand | APP MEDIA | Media |
| SNOOZE | Snooze | MUTE | Mute |