Mandis shop

Sony RM-SC30

Original		Replacement	
	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
DISPLAY	Display	DISPLAY INFO	Info
SELECT	Select	-/-- GUIDE	Guide
SET	Set Clock/Timer	FAV PRE-CH	Pre Ch
TUNER MEMORY	Tuner Memory	REC MODE	Rec
AUDIO IN	Audio In	A	Red
PLAY MODE/ TUNING MODE	Play Mode/Tuning Mode	SHIFT + PLAY MODE	Shift + Play
CD	CD	C	Yellow
REPEAT/ FM MODE	Repeat/FM	REPEAT TEXT	Text
TUNER BAND	Band/Tuner	B	Green
FUNCTION	Function	TOP MENU MENU	Menu
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>
	Play	PLAY MODE	Play

Original		Replacement	
	Pause		Pause
	Stop		Stop
ENTER	Enter	OK	Ok
VOLUME	Vol +	VOL +	Vol +
VOLUME	Vol -	VOL -	Vol -
	Folder +	CH +	Ch +
	Folder -	CH -	Ch -
CLEAR	Clear	CLEAR EXIT	Exit
EQ	EQ	SETTINGS OPT	Options