| Original | | Replacement | |
|---|---|---|---|
| Sleep | SLEEP | Sleep / Timer | TIMER SLEEP |
| Power | | Power | |
| Clock Timer | CLOCK SELECT | Picture / Format | FORMAT PICTURE |
| Clock/Timer Set | CLOCK/TIMER SET | Zoom / Size | SIZE ZOOM |
| FM Mode | FM MODE | Down | |
| Group | GROUP | Red / Netflix / Search | NETFLIX SEARCH |
| Group Skip | GROUP SKIP | Yellow / YouTube / Repeat | YouTube REPEAT A-B |
| Tuning Mode | TUNING MODE | Up | |
| Menu/No | MENU/NO | Menu / Home | HOME MENU |
| Name Edit/Select | NAME EDIT/ SELECT | CH- / Page- | CH PAGE − |
| Enter/Yes | ENTER/YES | OK | OK |
| 1 | 1 | 1 | TV 1 |
| 2 | 2 | 2 | DVD 2 |
| 3 | 3 | 3 | CD - STB 3 |
| 4 | 4 | 4 | VIDEO 4 |
| 5 | 5 | 5 | TAPE 5 |
| 6 | 6 | 6 | TUNER 6 |

| Original | | Replacement | |
|---|---|---|---|
| 7 | 7 | 7 | AUX - HDD 7 |
| 8 | 8 | 8 | USB 8 |
| 9 | 9 | 9 | BLUETOOTH 9 |
| >10 | +10 | Guide / EPG / -/-- | -/-- GUIDE EPG |
| 10/0 | 10/0 | 0 | HDMI - SAT 0 |
| CLEAR | Clear | Exit / Cancel / Clear | CLEAR EXIT CANCEL |
| CURSOR ◀◀ | << | << / Tune- | TUNE- ◀◀ |
| CURSOR ◀◀ | ← Cursor | Left | ◀ |
| SCROLL | Scroll | CH+ / Page+ | CH PAGE + |
| CURSOR ▶ | Cursor → | Right | ▶ |
| CURSOR ▶▶ | >> | >> / Tune+ | TUNE+ ▶▶ |
| | I<</- | I<< / Preset- | PRESET- ⏮ |
| DISPLAY | Display | Display / Media | MEDIA DISPLAY |
| | >>I / + | >>I / Preset+ | PRESET+ ⏭ |
| FUNCTION | Function | Smart / List | LIST SMART |
| TUNER B VD | Tuner/Band | Shift + 6 | SHIFT + TUNER 6 |
| TUNER B VD | Tuner/Band | Info / Angle | ANGLE INFO |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Play/Pause MD | Pause / Step / Freeze | | |
| Play/Pause CD | Play / Slow | | |
| <> Tape | Eject / Surround | | |
| <> Tape | Shift + Play / | | |
| Rec MD | Rec / Rec Mode | | |
| Stop | Stop / Hold | | |
| Vol + | Vol + | | |
| Play Mode | Setup / OPT / | | |
| Repeat | Green / APP / Repeat | | |
| DSG | Sound / Title | | |
| Bass/Tre | Audio / Lang I/II | | |
| Vol - | Vol - | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |