Mandis shop

Sony RMT-830

Original	Replacement	Original	Replacement
Photo	Smart / List		
Start Stop	Power		
T	CH+ / Page+		
Search M	Red / Netflix / Search		
I <<	I << / Preset-		
>>I	>>I / Preset+		
W	CH- / Page-		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		
Slow I >	Shift + Play /		
Slow I >	Right		
Zero Set	Green / APP / Repeat		
Display	Display / Media		

https://mandisshop.eu/Sony-1007-692-replacement-remote-control-for-Sony-RMT-830-14892.htm