Mandis shop

Sony RM-DC335

Original		Replacement	
CONTINUE	Continue Play	GOTO TEXT	Text / Goto
SHUFFLE	Shuffle Play Mod	RDS AV INPUT	AV / Input / RDS
PROGRAM	Program Play	OPT-TOOLS SETUP	Setup / OPT /
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
CHECK	Check	MEDIA DISPLAY	Display / Media
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TIME	Time	TIMER SLEEP	Sleep / Timer
FADER	Fader	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Replacement	
>10	>10	-/-- GUIDE EPG	Guide / EPG / -/--
10/0	10/0	HDMI-SAT 0	0
DISC 1	Disc 1	NETFLIX SEARCH	Red / Netflix / Search
DISC 2	Disc2	APP REPEAT	Green / APP / Repeat
DISC 3	Disc3	YouTube REPEAT A-B	Yellow / YouTube / Repeat
DISC 4	Disc4	Prime Video RANDOM	Blue / Prime Video / Random
DISC 5	Disc5	LIST SMART	Smart / List
DISC SKIP	Disc Skip	PC FAV MARKER	Fav / Marker / PC
▷	Play	SLOW ▶	Play / Slow
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
AMS ⏮	I << AMS	PRESET- ⏮	I << / Preset-
AMS ⏭	AMS >>I	PRESET+ ⏭	>>I / Preset+
ANALOG OUT LEVEL	Analog Out	+ VOL	Vol +
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
	Analog Out Level	VOL −	Vol -

https://mandisshop.ie/en/Sony/10761-720-replacement-remote-control-for-Sony-RM-DC335-148041.htm