Original	Replacement	Original	Replacement
Power	Power	Display/Tools	Setup / OPT /
Muting	Mute / Dimmer	One-Touch Play	Text / Goto
Play	Play / Slow	Menu/DVD	Menu / Home
Pause	Pause / Step / Freeze	Theatre	TV/Radio /
Stop	Stop / Hold	Up	Up
<<	<< / Tune-	Angle	Info / Angle
>>	>> / Tune+	Left	Left
I<</Preset-	I<< / Preset-	OK	OK
>>I/Preset+	>>I / Preset+	Right	Right
Sound Mode	Sound / Title	Clear	Exit / Cancel / Clear
Audio	Audio / Lang I/II	Down	Down
Subtitle/D.Tuning	Subtitle / EQ	Return	Back / Return
Picture Navi	Picture / Format	Volume+	Vol +
S-Air Mode	Zoom / Size	Dynamic Bass	Smart / List
Sleep	Sleep / Timer	Function+	CH+ / Page+
Tv Input	AV / Input / RDS	Volume-	Vol -
System Menu/Enter	D.Menu / Top Menu	Display	Display / Media

Original		Replacement	
	Function-	CH PAGE –	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
NIGHT	Night	NETFLIX SEARCH	Red / Netflix / Search
DVD TOP MENU	DVD Top Menu	APP REPEAT	Green / APP / Repeat
DISC SKIP	Disc Skip	Prime Video RANDOM	Blue / Prime Video / Random
TV I/⏻	Power Tv	SHIFT + ⏻	Shift + Power
–	Tv Vol -	SHIFT + VOL –	Shift + Vol -
TV VOL +	Tv Vol +	SHIFT + + VOL	Shift + Vol +

Original		Replacement	
ADVANCE	· →/ I > Step/ Advance	SHIFT + TUNE+	Shift + >> /
REPLAY	← / ◁ Step/ Repla	SHIFT + TUNE-	Shift + << /

Original		Replacement	
I/⏻	Power		Power
TV VOL +	Tv Vol +	VOL +	Vol +
TV INPUT	Tv Input	RDS AV INPUT	AV / Input / RDS
TV VOL –	Tv Vol -	VOL –	Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/-- CLEAR	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
SYSTEM MENU ENTER	Enter	PC FAV MARKER	Fav / Marker / PC
DVD MENU	Menu	HOME MENU	Menu / Home

Original		Replacement	
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	Up		Up
	Left		Left
	OK	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
TOOLS DISPLAY	Tools	OPT-TOOLS SETUP	Setup / OPT /
PROG – PRESET –	Prog-	CH PAGE –	CH- / Page-
PROG + PRESET +	Prog+	CH PAGE +	CH+ / Page+