Mandis shop

Sony RMT-DS11

Original	Replacement	Original	Replacement
Power	Power	Pause	Pause / Step / Freeze
TC Reset	Exit / Cancel / Clear	Rec	Rec / Rec Mode
Display	Display / Media	<</ REW	<< / Tune-
Data Code	Shift + Display / Media	Play	Play / Slow
Search Select	AV / Input / RDS	>>/ FF	>> / Tune+
I <<	<< / Preset-	Stop	Stop / Hold
>>I	>> / Preset+		
Menu	Menu / Home		
↑	Up		
Set	Setup / OPT /		
↓	Down		
<<	CH- / Page-		
>>	CH+ / Page+		
x1/10	Red / Netflix / Search		
x1/3	Green / APP / Repeat		
x1	Yellow / YouTube / Repeat		
x2	Blue / Prime Video / Random		

https://mandisshop.eu/Sony-1062079-replacement-remote-control-for-Sony-RMT-DS11-176431.htm