Original		Replacement	
	Power MD		Power
	Direct Tuning	REPEAT TEXT	Text
	Dimmer	FAV PRE-CH	Pre Ch
	TV	SEARCH TV/R	TV/R
	CD	C	Yellow
	DVD	D	Blue
	Tuner/Band	B	Green
	Tape	A	Red
	VCR	HOME SMART	Smart
	MD	APP MEDIA	Media
	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
	Muting	MUTE	Mute
	Stop MD	■	Stop
	Play MD	PLAY MODE ▶	Play
	<<|<< MD	«	<<
	>>|>>| MD	»	>>

Original		Replacement	
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter	OK	Ok
	Menu	E-MANUAL D.MENU	D. Menu
	Display	DISPLAY INFO	Info
	Top Menu/Disc/Deck	TOP MENU MENU	Menu
	1 MD	1	1
	2 MD	2	2
	3 MD	3	3
	4 MD	4	4
	5 MD	5	5
	6 MD	6	6
	7 MD	7	7
	8 MD	8	8
	9 MD	9	9

Original	Replacement
0 MD	0
>10/-/-- MD	GUIDE Guide
Tv/AV	TIMER AV
Stereo	SOUND DUAL
Surround	SETTINGS OPT
SFC	AD SUBT
Test	RETURN BACK
Delay	PICTURE FORMAT
Level	ECO 3D
+	+ CH
-	CH −
Power TV	SHIFT + Power
Tv Vol Up	SHIFT + + VOL
Tv Vol Down	SHIFT + VOL −
1 Tv	SHIFT + 1
2 Tv	SHIFT + 2
3 Tv	SHIFT + 3

Original	Replacement
4 Tv	SHIFT + 4
5 Tv	SHIFT + 5
6 Tv	SHIFT + 6
7 Tv	SHIFT + 7
8 Tv	SHIFT + 8
9 Tv	SHIFT + 9
0 Tv	SHIFT + 0
>10/-/-- Tv	SHIFT + GUIDE Shift + Guide

Original		Replacement	
	Power DVD		Power
	TV	SEARCH TV/R	TV/R
	VCR	HOME SMART	Smart
	Tuner/Band	B	Green
	Tape	A	Red
	MD	APP MEDIA	Media
	CD	C	Yellow
	DVD	D	Blue
	Play DVD	PLAY MODE	Play
	I<<<< DVD	<<	<<
	Stop DVD		Stop
	>>>>I DVD	>>	>>
	Top Menu/Disc/Deck	TOP MENU MENU	Menu
	Display	DISPLAY INFO	Info
	Menu	E-MANUAL D.MENU	D. Menu
	Up		Up
	Down		Down

Original		Replacement	
	Right		Right
	Left		Left
	Enter	OK	Ok
	Stereo	SOUND DUAL	Dual
	Surround	SETTINGS OPT	Options
	SFC	AD SUBT	Subt
	Test	RETURN BACK	Back
	Delay	PICTURE FORMAT	Format
	Level	ECO 3D	3D
	+	+ CH	Ch +
	-	CH –	Ch -
	1 DVD	1	1
	2 DVD	2	2
	3 DVD	3	3
	4 DVD	4	4
	5 DVD	5	5
	6 DVD	6	6

Original		Replacement		Original	Replacement
7	7 DVD	7	7		
8	8 DVD	8	8		
9	9 DVD	9	9		
0	0 DVD	0	0		
≥10/-/--	>10/ - / - - DVD	-/-- GUIDE	Gui de		
VOL +	Vol +	+ VOL	Vol +		
VOL −	Vol -	VOL −	Vol -		
MUTING	Mut i ng	MUTE	Mut e		

Original		Replacement	
	Power CD		Power
	TV	SEARCH TV/R	TV/R
	VCR	HOME SMART	Smart
	CD	C	Yellow
	DVD	D	Blue
	Tape	A	Red
	MD	APP MEDIA	Media
	Tuner/Band	B	Green
	Stop CD		Stop
	I<<</<< CD	<<	<<
	>>/>>I CD	>>	>>
	Play CD	PLAY MODE	Play
	Menu	E-MANUAL D.MENU	D. Menu
	Display	DISPLAY INFO	Info
	Top Menu/Disc/Deck	TOP MENU MENU	Menu
	Up		Up
	Down		Down

Original		Replacement	
	Right		Right
	Left		Left
	Enter	OK	Ok
	Stereo	SOUND DUAL	Dual
	Surround	SETTINGS OPT	Options
	SFC	AD SUBT	Subt
	Test	RETURN BACK	Back
	Delay	PICTURE FORMAT	Format
	Level	ECO 3D	3D
	+	+ CH	Ch +
	-	CH −	Ch -
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Muting	MUTE	Mute
	Power Tape	SHIFT +	Shift + Power
	Stop Tape	SHIFT +	Shift + Stop
	Play Tape	SHIFT + PLAY MODE	Shift + Play

Original	Replacement	Original	Replacement
I <<| << Tape	SHIFT + << Shift + <<		
>>| >>I Tape	SHIFT + >> Shift + >>		
Top Menu/ Disc/ Deck	SHIFT + TOP MENU MENU Shift + Menu		
1 CD- Tape	1 1		
2 CD- Tape	2 2		
3 CD- Tape	3 3		
4 CD- Tape	4 4		
5 CD- Tape	5 5		
6 CD- Tape	6 6		
7 CD- Tape	7 7		
8 CD- Tape	8 8		
9 CD- Tape	9 9		
0 CD- Tape	0 0		
>10/ - / - - CD- Tape	-/-- GUIDE Guide		
Direct Tuning/ Disc Ente	REPEAT TEXT Text		

Original		Replacement	
	Power VCR		Power
DIMMER	Dimmer	FAV PRE-CH	Pre Ch
VCR	VCR	HOME SMART	Smart
TAPE	Tape	A	Red
TV	TV	SEARCH TV/R	TV/R
CD	CD	C	Yellow
DVD	DVD	D	Blue
TUNER/ BAND	Tuner/Band	B	Green
MD	MD	APP MEDIA	Media
	Stop		Stop
	I <<<<	<<	<<
	>>>>I	>>	>>
	Play	PLAY MODE	Play
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4

Original		Replacement	
5	5 VCR	5	5
6	6 VCR	6	6
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
≥10/-/--	>10/-/-- VCR	-/-- GUIDE	Guide
DIRECT TUNING DISC ENTER	Direct Tuning/Disc Ente	REPEAT TEXT	Text
VOL +	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
MUTING	Muting	MUTE	Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu

1/2

Original	Replacement
DISPLAY Display	DISPLAY INFO Info
MENU Menu	E-MANUAL D.MENU D. Menu
STEREO Stereo	SOUND DUAL Dual
SURROUND Surround	SETTINGS OPT Options
SFC SFC	AD SUBT Subt
TEST Test	RETURN BACK Back
DELAY Delay	PICTURE FORMAT Format
LEVEL Level	ECO 3D 3D
+ +	+ CH Ch +
- -	CH − Ch -
Power Tuner / Band	SHIFT + Power Shift + Power
1 1 Tuner / Band	SHIFT + 1 Shift + 1
2 2 Tuner / Band	SHIFT + 2 Shift + 2
3 3 Tuner / Band	SHIFT + 3 Shift + 3
4 4 Tuner / Band	SHIFT + 4 Shift + 4
5 5 Tuner / Band	SHIFT + 5 Shift + 5
6 6 Tuner / Band	SHIFT + 6 Shift + 6

Original	Replacement
7 7 Tuner / Band	SHIFT + 7 Shift + 7
8 8 Tuner / Band	SHIFT + 8 Shift + 8
9 9 Tuner / Band	SHIFT + 9 Shift + 9
0 0 Tuner / Band	SHIFT + 0 Shift + 0
≥10/-/-- >10/-/--	SHIFT + -/-- GUIDE Shift + Guide