Original		Replacement	
STANDBY	Standby		Power
USB/CARD	USB/Card	SHIFT + USB 8	Shift + 8
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0/10	0/10	HDMI - SAT 0	0

Original		Replacement	
MENU	Menu	HOME MENU	Menu / Home
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TITLE	Title	TITLE SOUND	Sound / Title
	Left		Left
	Up		Up
	Right		Right
ENTER	Enter	OK	OK
	Down		Down
REV	<<	TUNE-	<< / Tune-
FWD	>>	TUNE+	>> / Tune+
PREV	I <<	PRESET-	I << / Preset-
NEXT	>>I	PRESET+	>>I / Preset+
STEP	Step	STEP - FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
PLAY/PAUSE	Play/Pause	SLOW	Play / Slow
VOL	Vol +	VOL	Vol +

Original		Replacement		Original	Replacement
REPEAT	Repeat	APP / REPEAT	Green / APP / Repeat		
A-B	A-B	YouTube / REPEAT A-B	Yellow / YouTube / Repeat		
ANGLE	Angle	ANGLE / INFO	Info / Angle		
MUTE	Mute	DIMMER / MUTE	Mute / Dimmer		
—	Vol -	VOL —	Vol -		
L/R	L/R	RDS / AV INPUT	AV / Input / RDS		
N/P	N/P	GOTO / TEXT	Text / Goto		
PBC	PBC	LIST / SMART	Smart / List		
SLOW	Slow	SHIFT + SLOW ▶	Shift + Play /		
V-MODE	V-Mode	TOP MENU / D.MENU	D.Menu / Top		
RETURN	Return	RETURN / BACK	Back / Return		
HD/Res.	HD/Res.	FORMAT / PICTURE	Picture / Format		
PROGRAM	Program	PROGRAM / TV/RADIO	TV/Radio /		
ZOOM	Zoom	SIZE / ZOOM	Zoom / Size		