Original		Replacement	
	Mute		Mute / Dimmer
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
	S	SETUP	Setup / OPT /
0	0	0	0
	Source	AV INPUT	AV / Input / RDS
	Menu/Menu	MENU	Menu / Home
GUIDE	Guide	GUIDE EPG	Guide / EPG / -/--
TV/FAV RADIO	Tv/Fav/Radio	TV/RADIO	TV/Radio / Program

Original		Replacement	
	Exit/Back	EXIT	Exit / Cancel / Clear
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	PR+	CH	CH+ / Page+
	Vol -	VOL	Vol -
	Vol +	VOL	Vol +
	PR-	CH	CH- / Page-
	[++]	SMART	Smart / List
	→I [/] I ←	DISPLAY	Display / Media
	[i +]	INFO	Info / Angle
	Text	TEXT	Text / Goto
	I I >/ [▼]	SHIFT + TUNE+	Shift + >> /
	Play/O) I / I I	SLOW	Play / Slow
	<<I [≡o]	TUNE-	<< / Tune-

Original		Replacement		Original	Replacement
SUBTITLE	>>/ Subtitle	TUNE+	>> / Tune+		
	Open/close/[≡?]	SURROUND	Eject / Surround		
	Stop/[≡+]	HOLD	Stop / Hold		
	I<<</[≡↕]	PRESET-	I<< / Preset-		
	>>I/[≡x]/[O]	PRESET+	>>I / Preset+		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		

Original	Replacement
Mute	Mute / Dimmer
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Menu/DVD	Menu / Home
Exit/Back	Exit / Cancel / Clear
Up	Up
Left	Left
OK	OK

Original	Replacement
Right	Right
Down	Down
Vol -	Vol -
Vol +	Vol +
▮▮/▮▮▶ / [▼]	Pause / Step / Freeze
▶ / I/II	Shift + Play /
▶ / I/II	Play / Slow
◀◀ / [≡◀]	<< / Tune-
◀◀ / [≡◀]	Shift + << /
▶▶ / Subtitle	Shift + >> /
▶▶ / Subtitle	>> / Tune+
▲	Eject / Surround
■ / [≡▯]	Stop / Hold
▮◀◀ / [≡↕]	I<< / Preset-
▮◀◀ / [≡↕]	Shift + I<< / Preset-
▶▶▮ / [◷][≡X]	Shift + >>I / Preset+
▶▶▮ / [◷][≡X]	>>I / Preset+

Original	Replacement
Mute	Mute / Dimmer
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
– 7	7
– 8	8
– 9	9
0	0
Source	AV / Input / RDS
P+	CH+ / Page+
Vol -	Vol -
Vol +	Vol +
P-	CH- / Page-

Original	Replacement
▮▮/▮▮▶ / [▼]	Pause / Step / Freeze
▶ / I/II	Shift + Play /
▶ / I/II	Play / Slow
◀◀ / [≡◀]	<< / Tune-
◀◀ / [≡◀]	Shift + << /
▶▶ / Subtitle	Shift + >> /
▶▶ / Subtitle	>> / Tune+
▲	Eject / Surround
■ / [≡□]	Stop / Hold
▮◀◀ / [≡↕]	Shift + I<< / Preset-
▮◀◀ / [≡↕]	I<< / Preset-
▶▶▮ / [◷][≡X]	Shift + >>I / Preset+
▶▶▮ / [◷][≡X]	>>I / Preset+