Mandis shop

DIGITAL-PHOTO-FRAME

Original		Replacement	
	Power		Power
AV-OUT	AV-Out	TIMER AV	AV
PHOTO	Photo	A	Red
MUSIC	Music	B	Green
MOVIE	Movie	C	Yellow
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
SETUP	Setup	SETTINGS OPT	Options
EXIT	Exit	CLEAR EXIT	Exit
CALEN DAR	Calendar	HOME SMART	Smart
	Play	PLAY MODE	Play
	Pause		Pause
	I<<		I<<
	>>I		>>I

Original		Replacement	
	<<		<<
	>>		>>
VOL+	Vol+	+ VOL	Vol +
VOL-	Vol-	VOL -	Vol -
	Mute	MUTE	Mute

https://mandisshop.ie/en/UNKNOWN/1061059-91309-replacement-remote-control-for-UNKNOWN-Digital-Photo-Frame.html