# Mandis shop

## Woxter I CUBE780

| Original | Replacement |
|---|---|
| Power | Power |
| Mute | Mute / Dimmer |
| Movie | 1 |
| Photo | 2 |
| Music | 3 |
| Browser | Display / Media |
| Setup | Setup / OPT / |
| Info | Info / Angle |
| >>/ FF | >> / Tune+ |
| >>I / Next | >>I / Preset+ |
| Vol + | Vol + |
| <</ FR | << / Tune- |
| I <</ Prev | I << / Preset- |
| Vol - | Vol - |
| Home | Menu / Home |
| Up | Up |
| Return | Back / Return |

| Original | Replacement |
|---|---|
| Left | Left |
| Enter | OK |
| Right | Right |
| Pause | Pause / Step / Freeze |
| Play | Play / Slow |
| Down | Down |
| Stop | Stop / Hold |
| Goto | Text / Goto |
| Repeat | Green / APP / Repeat |
| Audio | Audio / Lang I/II |
| Rotate | Smart / List |
| Zoom | Zoom / Size |
| Sub-T | Subtitle / EQ |
| 16:9 | Picture / Format |
| AV | AV / Input / RDS |
| HDMI | 0 |

https://mandisshop.eu/Woxter/1337-263-replacement-remote-control-for-Woxter-I-Cube780.htm