Original		Replacement	
	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
DIMMER	Dimmer	HOME SMART	Smart
A SPEAKER	A Speakers	A	Red
PEAKERS B	Speakers B	B	Green
PHONO	Phono	1	1
TAPE	Tape	2	2
CD	CD	3	3
DOCK	Dock	4	4
LINE 1	Line 1	5	5
LINE 2	Line 2	6	6
FM	FM	7	7
AM	AM	9	9
PRESET	< Preset	C	Yellow
PRESET	Preset >	D	Blue
TP	TP	APP MEDIA	Media
INFO	Info	DISPLAY INFO	Info

Original		Replacement	
SHUFFLE	X/Shuffle	RETURN BACK	Back
REPEAT /RETURN	Repeat/Return	REPEAT TEXT	Text
	▲	+ CH	Ch +
	▼	CH −	Ch -
MENU	Up/Menu		Up
	Down/Play/Paus		Down
	Right/>>I		Right
	I<<</Left		Left
ENTER	Enter	OK	Ok
+ VOLUME	Volume+	+ VOL	Vol +
VOLUME −	Volume-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
OPTION	Option	SETTINGS OPT	Options
	Stop	■	Stop
	Pause	II	Pause
	Play	PLAY MODE ▶	Play
DISC SKIP	Disc Skip	SEARCH TV/R	TV/R

Original		Replacement		Original	Replacement
	I <<		I <<		
	>>I		>>I		
	Open/Close	ZOOM	Eject		
	<<		<<		
	>>		>>		