Original		Replacement	
STANDBY/ON	Standby/on		Power
SYNCHRO	Synchro	HOME MENU	Menu / Home
DIMMER	Dimmer	DIMMER MUTE	Mute / Dimmer
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
TEXT/TIME	Text/Time	GOTO TEXT	Text / Goto
PEAK	Peak	RETURN BACK	Back / Return
TAPE	Tape	SHIFT + TAPE 5	Shift + 5
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8

Original		Replacement	
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
INDEX	Index	ANGLE INFO	Info / Angle
MODE	Mode	FORMAT PICTURE	Picture / Format
OUTPUT	Output Level -		Left
LEVEL +	Output Level +		Right
DISC SCAN	Disc Scan	EQ SUBTITLE	Subtitle / EQ
DISC	< Disc Skip	CH PAGE −	CH- / Page-
SKIP	Disc Skip >	+ CH PAGE	CH+ / Page+
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
	Pause	STEP-FREEZE	Pause / Step / Freeze
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
	I <<	PRESET-	I << / Preset-
	Play	SLOW	Play / Slow
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-

Original	Replacement	Original	Replacement
Stop	HOLD Stop / Hold		
>>	TUNE+ >> / Tune+		