







































































Original	Replacement	Original	Replacement
 Power	 Power	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 P+	 Ch +
 3	 3	 P-	 Ch -
 4	 4	 Mute	 Mute
 5	 5	 Menu	 Menu
 6	 6	 Red	 Red
 7	 7	 Green	 Green
 8	 8	 Yellow	 Yellow
 9	 9	 Blue	 Blue
 0	 0	 OK	 Ok
 Recall	 Pre Ch	 Up	 Up
 Input	 AV	 Down	 Down
 ATV	 Shift + Smart	 Right	 Right
 DTV	 Smart	 Left	 Left
 EPG	 Guide	 End	 Exit
 Radio	 TV/R	 Back	 Back



