

































































































| Original | Replacement |
|--|--|
|  Power |  Power |
|  Mute |  Mute |
|  Sleep |  Sleep |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0/AV |  0 |
|  Rec |  Rec |
|  Tv/Radio |  TV/R |
|  << |  << |
|  Stop/DVR |  Stop |

| Original | Replacement |
|---|---|
|  Play/Pause |  Play |
|  >> |  >> |
|  SFI |  Guide |
|  www |  Media |
|  ↑ |  >> |
|  ↓ |  << |
|  Recall/Zurück |  Back |
|  Info/Vor |  Info |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  Ok |
|  P+ |  Ch + |
|  P- |  Ch - |
|  OPT |  Options |
|  NAV |  List |





| Original | | Replacement | | Original | Replacement |
|---|----------|---|--------|----------|-------------|
|  | Vol+ |  | Vol + | | |
|  | Vol- |  | Vol - | | |
|  | Red |  | Red | | |
|  | Green |  | Green | | |
|  | Yellow |  | Yellow | | |
|  | Blue |  | Blue | | |
|  | Menu |  | Menu | | |
|  | ♪/Ton |  | Dual | | |
|  | Timer |  | AV | | |
|  | Zoom |  | Eject | | |
|  | TXT |  | Text | | |
|  | I>/Still |  | Pause | | |
|  | HDMI |  | Smart | | |
|  | PIP |  | 3D | | |
| | | | | | |
| | | | | | |
| | | | | | |

