





































| Original | Replacement |
|---|---|
|  Standby - On |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Browser |  Smart |
|  Timer |  Sleep |
|  Menu System |  Menu |
|  Menu Disc |  D. Menu |
|  Up |  Up |
|  CH+ |  Ch + |

| Original | Replacement |
|--|--|
|  CH- |  Ch - |
|  Down |  Down |
|  OK |  Ok |
|  Right |  Right |
|  Left |  Left |
|  Play |  Play |
|  Select |  Info |
|  Edit |  TV/R |
|  Stop |  Stop |
|  Rec |  Rec |
|  Pause |  Pause |
|  I<< |  I<< |
|  >>I |  >>I |
|  Return |  Back |
|  Red |  Red |
|  Green |  Green |
|  Yellow |  Yellow |





| Original | Replacement |
|----------|-------------|
| Blue | Blue |
| Tv Vol+ | Vol + |
| Tv Vol- | Vol - |
| T/C | Guide |
| Rec Mode | Shift + Rec |
| Tuner | Subt |
| TV / DVD | AV |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |





| Original | Replacement |
|--------------|-------------|
| Standby - On | Power |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| Timer | Sleep |
| Up | Up |
| CH+ | Ch + |
| CH- | Ch - |
| Down | Down |
| OK | Ok |

| Original | Replacement |
|-------------|-------------|
| Rec | Rec |
| Return | Back |
| Red | Red |
| Green | Green |
| Yellow | Yellow |
| Blue | Blue |
| Tuner | Subt |
| T/C | Guide |
| Tv Vol+ | Vol + |
| Tv Vol- | Vol - |
| TV / DVD | TV/R |
| Menu System | Menu |

